Assembly Instructions

Your recliner comes packaged in One box. Carefully remove all of components from the packaging and set aside for assembly.

CAUTION:

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Package Contents

A*1	B*1	C*1	D*1
			
E*1	**F*1**	**G*1**	**H*2**
			

Step1:Find a small bag in the accessories box.Take out **Supporting Feet(H)** from the small bag.Assemble the two **Supporting Feet** as shown on the bottom of mechanismto avoid toppling and falling.The **Armrests(C)** and **(D)** are on the bottom of the seat.Please find them on the bottom of the seat.



Step 2: Connect the **Armrest(C)** and **(D)** to the **Chair Seat(A).**



Step 3: Connect the **Chair Back(B)** to the **Chair Seat(A)** by aligning the metal grooves and sliding down to the bottom.



Step 4: Connect Power Cords.**No.1** and **No.2** wires connect the backrest to the chair seat.**No.3** wire connects the backrest to the **power cords(F)**.**No.4** wire connects up the backrest and **massage remote(G)**.**No.5** connects the motor with the wire from right armrest,which has a control panel.**No.6** wire connects the motor to the **power source(E)**.



Note:

1.The connection plugs have different colors,black to black, white to white,red to red.

2.Plug both the **Power Cord(F)** and **Power Source(E)**into outlet to get the recliner working.

Different positions by pressing the buttons of left armrest to switch,the lift recliner chair can meet your various needs.

Operation Instruction



Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please DO NOT sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
   a) Check if all the cables are connected;
   b) Check if the light of transformer is on.

   If the chair still doesn't work, please feed the information back to our customer service in time and we'll help you solve the matter as soon as possible.