Wall Lamp



Model Number:
FI1066 (UNO-BA-331)

Technical Data: Bulb Socket: G9*1
Max40W, 220-240V~,50/60Hz,IP20

EC REP

SYL Moda Trading LTD
Po Box 148,Manchester,M266BJ,United Kingdom
sylmodatradingltd@gmail.com

	C01	1
	C02	1
	C03	1
	C04	1



⚠ Safety Instructions ⚠

- Before use, check that the power supply corresponds to that which is stated on the device's nameplate. Avoid any unintentional startup.
- Do not allow water or other liquids to get into the appliance. Do not expose it to rain.
- Do not use the appliance if the plug, the mains cord or other components are damaged.
- If the mains cord is damaged, you must have it replaced by a service

General Safety Warnings

- The product must not be exposed to extreme temperatures, high humidity or strong mechan-ical stress.
- Keep children away from the lamp, and do not leave them unsupervised with the lamp.
- Do not look directly into the light source! Your eyes could be damaged.
- Let the lamp cool down completely before changing the bulb. Risk of burning.
- Always place the lamp on an even and stable surface to prevent it tipping.
- Keep the lamp away from heat sources.

Maintenance and Care

- Before cleaning or maintenance the florr lamp, unplug the power cord from the wall outlet. Wait until the lamp has cooled down.
- The lamp is maintenance-free for you apart from a change of the lamp.
- Clean the lamp only with a sofrt, dry cloth. Do not use solvent based-cleaners or detergents for example Bleach those can damagethe product.



Correct disposal of this product

Within the EU, this symbol indicates that this product must not be disposed of with household waste. Old devices contain valuable recyclable materials that should be recycled and not harm the environment or human health through uncontrolled waste disposal. Please dispose of old devices using suitable collection systems or send the device to the place where you bought it for disposal. This will then send the device to sto recycling.