ASSEMBLY INSTRUCTIONS

1. Two or more people are needed to complete the installation.
2. Please protect the wires and remote control accessories from damage during installation.
3.Professional installation is highly recommended.
4.Assemble on a flat,clean and soft surface.

Item no.	Reference Image	Qty.
1		X1
2		X1
3		X1
4		X1
5		X1
6		X1
7		X1
8		X1
9		X1

Item no.	Reference Image	Qty.
10		X1
11		X1
12		X1
13		X1
14		X1
15		X1
16		X1
17		X1
18		X2

Item no.	Reference Image	Qty.
19		X2
20		X2
21		X2
22		X1
23		X1
24		X2
25		X2
26		X2
27		X2

Item no.	Reference Image	Qty.
28		X1
29		X1
30		X1
31		X1
32		X1
33		X2
34		X2
35		X2
36		X1

Item no.	Reference Image	Qty.
A		X49
B		X49
C	ϕ8X40mm	X20
D	ST3.5X14mm	X34
E	ST3.5X35mm	X16
F	M7X50mm	X10
G	M6X25mm	X2
H	M6X30mm	X12
I	M6X40mm	X8
J	M6X60mm	X2

Item no.	Reference Image	Qty.
K		X3
L		X1
M	M4X18mm	X8
N		X1
O	O1 O2 O3 O4 O5	X2
P	P1 P2	X4
Q		X4
R		X6
S		X1



USING CAM LOCK AND QUICKFIT

Tighten quickfit until shoulder is flush with panel.Do not overtighten or undertighten.



When fitting cam lock,ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.

Turn cam lock clockwise to tighten.



PRE-FIX DRAWER RUNNER INSTRUCTIONS

Pull inner and outer drawer runners apart before fixing them to panels.

Slide drawer runners apart until the drawer lock can be seen, as shown.



Press and hold the drawer runner lock and then continue to slide drawer runners apart, as shown.



Your inner and outer drawer runners are ready to be fixed to panels.



⚠ When installing the outer guide rail, please use the guide rail notch to assemble towards the inner direction of the drawer. Please fix the screws according to the marked position. If the installed position is changed, adjust it side-to-side at the marked position.

⚠ When installing the inner guide rail, please use the guide rail notch to assemble towards the inner direction of the drawer. Please fix the screws according to the marked position. If the installed position is changed, adjust it up and down at the marked position.

1



①1pc ⑥1pc ⑦1pc ⑧1pc ⑨1pc Ⓐ19pcs Ⓒ6pcs



2



③1pc ④1pc ⑤1pc ⑪1pc ⑫1pc ⑬1pc ⑭1pc Ⓐ8pcs Ⓒ14pcs



3


P1
Ⓓ8pcs
Ⓟ2pcs


D
D
P1
P
3
P1
D
D
4
D
P1
D
5
D
P1
D
D
5
P1
D
D
D
D
P1
P

4


P1
Ⓓ8pcs
Ⓟ2pcs


D
D
P1
13
P1
D
D
P1
D
D
14
D
P1
D
D
P1
D

5

Ⓑ9pcs



6

Ⓑ4pcs Ⓕ4pcs



7



②1pc ⑩1pc Ⓕ6pcs



8

Ⓑ6pcs



9



㉘1pc ㉙1pc ㉚1pc Ⓙ2pcs Ⓡ2pcs



10

Ⓗ6pcs



11



⑮1pc Ⓑ4pcs



12

㉛1pc ㉜1pc Ⓑ4pcs Ⓓ2pcs Ⓝ1pc Ⓠ4pcs







13

Ⓐ6pcs Ⓑ6pcs Ⓖ2pcs







14



⑯1pc ⑰1pc ㉒1pc ㉓1pc Ⓐ16pcs









15



⑱2pcs ⑲2pcs ⑳2pcs ㉑2pcs Ⓑ8pcs Ⓔ8pcs



16



㉔2pcs ㉕2pcs ㉖2pcs ㉗2pcs Ⓑ8pcs Ⓔ8pcs



17


P2
Ⓓ16pcs
Ⓟ4pcs
Ⓚ3pcs
Ⓛ1pc
Ⓜ8pcs


18
20
M
M
K
19
16
18
20
M
M
K
19
17
D
D
P2
24
26
M
M
22
K
25
24
26
M
M
L
23
25

18


6
1
17
16
22
23
P1
P2

19

Ⓢ1pc





Pull it out



Fix the bulb first.



Connect the bulb & wires.

20

Ⓞ1 1pc Ⓞ2 2pcs





21



01 1pc 03 2pcs 04 2pcs











After the cabinet assembly, please install the wall fixing device on the back of the cabinet to avoid accidents.

Install at a location based on your needs.

22

05 2pcs





23



㉝2pcs ㉞2pcs ㉟2pcs Ⓘ8pcs Ⓡ4pcs



24

㊱1pc Ⓗ6pcs



25

According to the specific usage needs, adjust the cabinet frame to switch the orientation from left to right or vice versa.



26



Installation Completed