
# TV & Media Furniture

## Television Stands & Entertainment Centers

Fireplace TV Stand for 70" TV



(24/7):service@kmcgloble-us.com

(USA) +1 213-816-4788

## ATTENTION ⚠

1. The product must be assembled and used according to the manual. The seller is not liable for any damage caused by incorrect assembly or misuse.
2. Do not sit or stand on the product.
3. Place the item on a flat surface.
4. Keep small parts away from children to avoid choking hazards.
5. Keep product away from corrosive gases, liquids and dusty environment.
6. Keep the original box(es) until assembly is complete or no quality issues need to be confirmed.

## AFTER-SALE SERVICE

If you have any suggestions or encounter quality issues with our products, please contact us first. Our after-sales team will respond within 24 hours, and we will do our best to provide a solution until you are satisfied.

## GUARANTEED CUSTOMER SERVICE

Your shopping experience is very important to us!
If you feel unsatisfied or have any questions, just contact us without any hesitation!
If you want to share how wonderful our smart product makes your home, you can share your pictures with us!
For further information, contacts immediately:


**service@kmcgloble-us.com**

# PARTS


1. Please ensure that all parts, accessories and installation tools are complete before starting the installation.
2. Due to the variety of accessories, some parts may be glued together, some parts may be trapped inside the larger ones, please check carefully.
3. In case you cannot find or lose some small parts or screws during installation, we have provided extra parts.
4. If any accessories are missing or damaged, please contact us immediately.

**service@kmcgloble-us.com**


## CARTON: A




**2** × 2




**6** × 1




**7** × 2




**12** × 1




**14** × 2




**15** × 1




**16** × 2




**17** × 1




**18** × 1



**19** × 2




**20** × 2




**21** × 2


## CARTON: A




22 × 2



25 × 1




26 × 1



27 × 1

## CARTON: A




M6x35mm

A × 80+4



Φ15x9mm

B × 80+4




M4x40mm

C × 24+2




Φ6x30mm

D × 30+2




M3x12mm


E × 28+2



F × 2




G × 1




Φ20mm


H × 16+2



I × 8




J × 4




M3.5x14mm

K × 32+2




L × 8



300mm

DR × 2




300mm

CL × 2



300mm

CR × 2




300mm

DL × 2




Anti-Tip Kit x2


## CARTON: B




1 × 1




3 × 1




4 × 1




5 × 1




8 × 1




9 × 2




10 × 2




11 × 1



13 × 2




23 × 2





24 × 2

# EXPLOSION VIEW





**1**









**2**








**3**









**4**





**5**











## 6






## 7








**8**








**9**








# 10




**11**




**12**



B x 14
H x 6



2
17
7
15
B x7
H x3
B
x7
H
x3
B
H
x3


B
x7
H
x3
B
H
x3
2
18
7
25
H x3
B x7


13



B × 14
H × 6



90°
26
2
17
7
15
B x7
H x3
B
x7
H
x3
B
H
x3


B
x7
H
x3
H
B
x3
90°
27
2
18
H x3
B x7
7
25


# 14



A x 4
CL x 1
E x 6
CR x 1


E
E
E
CL
E
E
E
CR



E x3
CL x1
A x2
26
17
15
A x2
E x3
CR x1
25
18
27


**15**








**16**







**17**








## 18






## 19




## 20









## 21







**22**







When the door of the cabinet is too high or too low





Loosen the height screws, then move the door up or down to make it level and then tighten the screws.

When the four sides of the cabinet door are not flush with the cabinet.





Adjust the lateral screws. Rotate the screws clockwise to increase the gap of the hinge, and rotate the screws counterclockwise to reduce the gap of the hinge until the four sides of the cabinet door are flush with the cabinet body.


When the gap between the position of the cabinet door hinge and the cabinet is either too large or too small.





Loosen the in-and-out screws, adjust the gap between the door and the cabinet to make it even, and then tighten the screws.

**23**






**24**



**25**




Ⓐ × 10





**26**





Ⓑ × 10




# 27



E × 12
DL × 2
DR × 2



E
E
E
DR



E
E
E
DL


E x6
DL x1
19
3
20
DR x1
E x6
DL x1
19
4
20
DR x1

# 28





**29**




**30**

1. Select a suitable location that is not susceptible to moisture.
2. Fix part A,B,C on the fireplace by 2 screws.(Fig A)






**31**


3. Fix the fireplace in the fireplace mantel by screws




**32**








**33**









**Drill a hole for installing anti-tip kit.**



**34**






# AFTER-SALE

## AFTER-SALE SERVICE

If you have any suggestions or encounter quality issues with our products, please contact us first.

Our after-sales team will respond within 24 hours, and we will do our best to provide a solution until you are satisfied.

## GUARANTEED CUSTOMER SERVICE

Your shopping experience is very important to us!

If you feel unsatisfied or have any questions,
**just contact us!**

If you want to share how wonderful our smart product makes your home, **just contact us** and share your pictures!

For further information,
**just contact us!**

service@kmcgloble-us.com
(USA) +1 213-816-4788