INSTRUCTION MANUAL



3PCS Cast Aluminum Bistro Set

SCD004-01-WKL

INTRODUCTION

Thanks for purchasing and trusting NUUGARDEN with your home decorating plans. This product is a piece of furniture designed and made by NUUGARDEN Corp.

We are committed to R&D and innovation and creating the most exquisite and diverse outdoor series.

After unpacking and before every use, check whether the item shows any damage. In addition, check that you have all parts and hardware before assembly. If there is any damage, please do not use it and call customer service at (800) 257-7108 or email service@nuugarden.com. If you do not have all the parts lists, have your dealer contact us and we will send them to you immediately.

This item of furniture is intended for indoor and outdoor use. Please take time to read and follow the instructions below. Then, use this item as described in this operating manual. We accept no liability for damage caused by improper use.







Part Number	Images and Sizes	Qty.
A		1
B		1
C		4
D		1
E		1
F	 M6*25	6
G	 M6	6
H	 M6	6

M	 M6	2	I	 M6	6
N		10	J	 M8	10
			K	 M8	10
			L	 M8	10

ASSEMBLY INSTRUCTIONS

CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 1

Attach the front and back Legs (C) to the chair seat (B) using studs (N), washers (J), and nuts (K, L). Do not tighten the nuts.

Attach the backrest (A) to the chair seat (B) using studs (N), washers (J), and nuts (K, L). Do not over-tighten.

ASSEMBLY INSTRUCTIONS

CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 2

Attach the right and left arm (D, E) using bolts (F), washers (G), and nuts (H, I). Then attach them to the backrest (A) and chair seat (B). Do not over-tighten.
Upon completion of the entire assembly and bolted up-all screws, you can be tightened down all screws. Next, add the protect hats (M).







Part Number	Images and Sizes	Qty.
A		1
B		1
C		3
D	 M8*30	6
E	 M8	9
F	 M8	9
G	 M8	9
H	 M8*30	3

ASSEMBLY INSTRUCTIONS

CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 1

Attach the 3 legs (C) to the tabletop (A) using studs(D), washers (E), and nuts (F, G). Do not over-tighten.

Attach the 3 legs (C) to the legs support (B) using bolts (H), washers (E), and nuts (F, G). Do not over-tighten.

Upon completing the entire assembly and bolting up, you can tighten down all screws.

CARE AND MAINTENANCE

Follow the instructions for the product's material to ensure it stays in the best shape as long as possible. The information below is a general guideline. Don't hesitate to get in touch with us to learn more.

• Only rinse it thoroughly with clean water to wash away dirt and grime. Never use abrasive cleansers on the furniture since they can attack the surface and leave behind scratch marks.

• For stubborn grime and stains, use a soft sponge and mild soapy water. Then dry it with a cloth or paper towel.

• Check the stability of the screws, nuts, and nut caps before each use. Then, tighten them up after one to two months' use whenever required.

• Avoid improper use, and be careful not to scratch or damage the surface with sharp objects.

• When you move your furniture, lift it rather than pulling or pushing it to avoid damaging the floor, legs, and mounting.

CUSTOMER SERVICE

Thanks for purchasing NUUGARDEN furniture. We are here to help you maximize your enjoyment and appreciation of it.

Please do not hesitate to contact our customer service if you have any questions regarding assembly or accessories.

Add: 6366 Corley Road, Norcross, GA 30071.

Tel: (800) 257-7108

Web: https://nuumart.com

E-mail: service@nuugarden.com

Service time: Mon-Fri, 8:30 AM-5:30 PM, EST