


FSDL-V1

BC-7045




















Notice:
1.Follow the installation instructions. Please confrm all accessories are preset before installation.
2.Do not fully tinhten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
3.If you encounter any problems during installation, please contact our customer service.
4.Please unbox the item from the side with an open-label and put a carpet on the foor to avoid seratching it.

 Recommended installers:2	 Put a carpet on the floor before unpacking	 Estimate installation time：60 minutes












ASSEMBLY INSTRUCTION











ASSEMBLY INSTRUCTION

❶ 1PC 	❷ 1PC 	❸ 1PC 	❹ 1PC 
❺ 1PC 	❻ 2PCS 	❼ 1PC 	❽ 1PC 
❾ 1PC 	❿ 2PCS 	⓫ 1PC 	⓬ 1PC 
⓭ 1PC 	⓮ 2PCS 	⓯ 2PCS 	⓰ 4PCS 
⓱ 1PC 	⓲ 1PC 	⓳ 2PCS 	⓴ 2PCS 

ASSEMBLY INSTRUCTION

21 4PCS 	22 1PC 	23 2PCS 	24 2PCS 
25 2PCS 	26 2PCS 	27 4PCS 	28 1PC 
29 1PC 	30 1PC 	31 1PC 	32 1PC 
33 1PC 	34 1PC 		


ASSEMBLY INSTRUCTION

A 103PCS +5PCS  M6*40	B 103PCS +5PCS  ϕ15*10	C 6PCS  14″	D 1PC 
E 95PCS  ϕ3.5*14	F 28PCS  ϕ3.5*35	G 2PCS 	H 8PCS 
I 4PCS 	J 4PCS 	K 16PCS  M4*18mm	L 1set 
M 103PCS 	N 1PC 		


ASSEMBLY INSTRUCTION

Use the Cam Lock and Eccentric Wheel
ECCENTRIC WHEEL

Tighten the bolt until the shoulder is aligned with the panel.
Be suer not to tighten too much or too little.



The pre-inserted nut should align with the center of the cam lock when joining two panels. The cam lock should be inserted before the eccentric wheel.



Turn the cam lock clockwise to tighten


ASSEMBLY INSTRUCTION


Step 1


A 103PCS





M6*40













































ASSEMBLY INSTRUCTION

Step 2

C 6PCS



14″



Step 3

C1 2PCS




14″

E 4PCS




φ3.5*14



ASSEMBLY INSTRUCTION

Step 4



C1 4PCS




14″

E 8PCS



ϕ3.5*14

Step 5



B 4PCS



ϕ15*10mm

ASSEMBLY INSTRUCTION


Step 6

B 4PCS



ϕ15*10mm

288mm=11.33″




Step 7

B 4PCS




ϕ15*10mm



ASSEMBLY INSTRUCTION

Step 8


B 4PCS



ϕ15*10mm

Step 9

B 10PCS




ϕ15*10mm

ASSEMBLY INSTRUCTION

Step 10

B 2PCS

ϕ15*10mm




Bx2

Step 11

B 4PCS

ϕ15*10mm




Bx4

ASSEMBLY INSTRUCTION

Step 12

B 12PCS

ϕ15*10mm




Step 13

B 4PCS


ϕ15*10mm

F 16PCS

ϕ3.5*35mm




x2



ASSEMBLY INSTRUCTION

Step 14


B 11PCS



ϕ15*10mm

Step 15

B 12PCS



ϕ15*10mm


H 8PCS



ASSEMBLY INSTRUCTION

Step 16


N 1PC



Step 17


B 12PCS

ϕ15*10mm



ASSEMBLY INSTRUCTION

Step 18



E 10PCS




φ3.5*14


G 2PCS



Step 19



x2



x2

E 16PCS



φ3.5*14

I 4PCS



J 4PCS



K 8PCS



M4*18mm


Step 20

Cabinet DoorAdjustment Instructions

Height adjustment:

a) Locate the height adjustment screws on the hinge.


b) Use the Phillips screwdriver to either tighten or loosen the screws to raise or lower the cabinet door as desired.



Side-to-side adjustment:

a) If the cabinet door needs to be moved closer to or away from the cabinet frame, locate the side - to-side adjustment screws on the hinge.

b) Use the Phillips screwdriver to adjust these screws and gradually move the door in the desired direction.




Depth adjustment (if applicable):

a) Check if the cabinet door needs to be brought closer to or further away from the cabinet frame.

b) For-depth adjustment, locate the depth adjustment screws on the hinge.


c) Use the Phillips screwdriver to turn these screws clockwise or counterclockwise accordingly.



ASSEMBLY INSTRUCTION

Step 21

E 16PCS




φ3.5*14

Step 22


E 16PCS


φ3.5*14





ASSEMBLY INSTRUCTION


Step 23


















B	12PCS
	ϕ15*10mm
C2	2PCS
	14″
D	1PC
E	17PCS
	ϕ3.5*14
F	4PCS
	ϕ3.5*35mm
K	4PCS
	M4*18mm


Step 24












x2

B	8PCS
	ϕ15*10mm
C2	4PCS
	14″
E	8PCS
	ϕ3.5*14
F	8PCS
	ϕ3.5*35mm
K	4PCS
	M4*18mm


ASSEMBLY INSTRUCTION

Step 25



Step 26

L 1set



OK