

ASSEMBLY INSTRUCTIONS




WARNING !




Estimated Time for Assembly

60 mins



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




① x1




② x1




③ x1




④ x1




⑤ x2




⑥ x2




⑦ x1




⑧ x1




⑨ x2




⑩ x1




⑪ x1




⑫ x1




⑬ x1




⑭ x1




⑮ x1




⑯ x1




⑰ x1



⑱ x1




⑲ x2




⑳ x2

BOARD IDENTIFICATION


Not actual size




21 x2



22 x2




23 x2




24 x2

Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




HARDWARE LIST



Ø6*33.5mm

A	x36+2



Ø15*9.5mm

B	x36+2




Ø6*30mm

C	x45+2



Ø5*40mm

D	x40+2



Ø4*40mm

E	x12+1



Ø4*20mm

F	x8+2



Ø3.5*12mm

G	x76+3



Ø3*14mm

H	x12+1




I	x3



J	x4




K	x1




L	x2



M	x5




N	x2



O	x6



P	x1




Q	x32




R	x12+1



S	x1




T	x1




U	x1




V	x2




W	x1




X	x2




CL	x2



CR	x2




DL	x2



DR	x2

STEP 1





CL	x 2

CR	x 2

G	x 12


STEP 2







A	x 20


STEP 3









STEP 4







STEP 5

Handle with care during installation







STEP 6




STEP 7







C	x 4




D	x 8


STEP 8









C	x 8




B	x 8


STEP 9






STEP 10








STEP 11




STEP 12






C x 3


D x 8


STEP 13









STEP 14







STEP 15





L	x 2
G	x 8

STEP 16












S	x 1
T	x 1
U	x 1


STEP 17






STEP 18






STEP 19




N	x 2


G	x 4


STEP 20




STEP 21











STEP 22















STEP 23







STEP 24







STEP 25







STEP 26













STEP 27













STEP 28





x 2














STEP 29



STEP 30



STEP 31



FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
· Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning