

Produced by **PT.Sinar Harapan Plastik**


If you have any question, please contact at
L843485741@outlook.com directly.

Made in Indonesia

VOLTA® TOYS

Item code :

VOLTA 5004



Manual Instructions

Pictures are only for reference.
Please read this book before installation and operation.
after reading, please keep this book for later using.

Produced by : **PT Sinar Harapan Plastik**
www.shptoys.com
Made in Indonesia

Table of contents 01
Instructions 02
Safe way of charging the battery 03
Parts diagram 04
Component diagram 05
Installation steps 06
How to operate a vehicle 08
How to recharge the vehicle 09
Maintenance for your vehicle 09
Troubleshooting & Solutions Guide 09
Battery disposal 10
How to use the remote control 11

Thank you for choosing our vehicle. Each part of the vehicle is designed using a unique model

As a vehicle that is imitated in a real and unique way, which can bring fun and different feelings to your children

Suitable for ages	**37 - 83 Months**	**Load capacity**	**< 25 Kg**
Speed	**3,5 - 4,5 KM/H**	**Vehicle size**	**88 X 49 X 35 cm**
Charger	**In : 100v/220-240, 50/60 Hz Out : 8v 700 MA**	**Battery version**	**12v 4,5AH**
Power	**Recharging type**	**Charging time**	**8 - 12 hour**
Fuse	**10 A**	**Avarage battery life**	**6 - 12 months**

Read carefully and follow all directions

⚠ WARNING **! BE CAREFUL**

Assembly / Use :

⚠ The product requires an adult to assemble. Children can be injured by small parts Sharp edges and sharp parts on assembled vehicles

⚠ Be careful when opening or assembling a vehicle, children should not handle parts or help assemble the vehicle

⚠ Always handle protective materials and polybags properly before assembling. children are prohibited from playing because it is dangerous

⚠ Suitable for children aged 37 - 96 months, and the maximum weight of use is 35 kg

⚠ Choking hazard to small parts, this product is prohibited for children under 3 years

⚠ To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water: always wear shoes, and never allow more than one ride(s)
RISK OF FIRE. Do not bypass. Replace only with fuse 10A.

! Do not play in the dark. Children can pass through obstacles Unexpected and be injured. Use during the day or in the light areas

⚠ Adult should check and maintain that all components are in good condition

⚠ To avoid damage to the motors and gears, stop the vehicle before changing from forward to reverse.

! Please select "O" when not driving. turn
off the power switch. (Warning: this button only to control the driving section)

! Do not allow other children to touch the wheel when the vehicle is moving.

! These vehicles are equipped with seat belts, please teach children how buckle before use.

! Do not exceed the maximum capacity of 35 kg.

Battery / Charger / Alkaline Batteries:

⚠ Battery / charger / alkaline batteries are not toys.

⚠ Do not recharge a.
non-rechargeable battery.

⚠ Do not mix old batteries and new batteries or batteries of the type different alkaline standard (carbon-zinc) or rechargeable batteries (nickel-cadmium).

⚠ Remove The rechargeable battery from the vehicle before recharging.

⚠ Remove the battery when not in use for a long period of time.

! Do not create a short circuit in the battery terminals.

⚠ Only use battery(ies) with battery(ies) specified by the manufacturer.

⚠ Only use the charger(s) specified by the manufacturer.

⚠ Do not open the battery and charger.

⚠ Battery care, Always keep dry.

Charger:

⚠ Recharge 4-6 hours before the first use, but do not recharge more than 10 hours.


⚠ Only adults should handle or recharge the batteries. Do not let children do.
recharging

! When the vehicle speed becomes slow recharge the battery
for 8-12 hours, do not recharge the battery for more than 18 hours.

⚠ Separate batteries, chargers and connectors to avoid shortage
every time you charge the battery. If damaged or overused do not use the charger until you have replaced the missing or damaged batteries and parts.

! Recharge the batteries in a dry place.

! Recharge the battery at least once a month, even if the vehicle not used.


Equipment required :
screwdriver
pliers
1
2
3
3
4
4
5
5
6
6
7
7
7
7
8
8
8
8
9
9
9
9
9
10
10
11
11
12
13
14
15


VOLTA TOYS

Riding vehicles will provide a comfortable driving experience.
To help ensure that you and your driver drive safely, We ask that you read this manual carefully and save it for later reference.

Follow the recommendations in this manual, which are made for safety and the operation of your riding vehicle


1	**Vehicle Body**	9	**Ring Plat**
2	**Steering Wheel**	10	**Front Wheel**
3	**Rearview Mirror**	11	**Front Wheel Extension**
4	**Gearbox**	12	**Rear Wheel Ring**
5	**Rear Wheel Extension**	13	**Charger**
6	**Rear Wheel**	14	**Remote Control**
7	**Velg**	15	**Safety Backstop**
8	**Cotter Pin**	16	

Pay attention and follow the installation instructions below




Steering Wheel Installation

- Connect the steering wheel socket to the socket inside the body, then insert the steering wheel into the steering axle, install it properly & align it to the bolt hole. Insert the bolt & tighten it




Rearview Mirror Installation

- Position the rearview mirror on the body, press it until it locks.



Back-up mounting


- Install the backrest on the body part bottom back then press until locked.





Battery Installation

- Insert the red wire into the red colomn +
  silence the black wire in the black column -
  under normal conditions.
  (ignore this condition if battery path has been installed condition)

Connect the red cable to the battery socket As shown in the picture below







Power button, forward / reverse button, manual RC button, speed button high / low on the instrument platform.
Power button: Press the power button to unlock and it will turn off it pressed again
Manual switch: Forward

1. Push the forward switch
2. Step on the pedal, the vehicle will move forward

Backward

1. Push the switch reverse
2. Step on the pedal, the vehicle will move backward

Remote controller : 1. Press the RC button
2. Then an adult can adjust the direction of the vehicle
Speed button, fast / slow


1. Press the fast / slow speed button to get fast speed / slow speed
2. Press forward / reverse vutton for forward / reverse position. step on the pedal, the vehicle will move forward or backward at fast / slow speed. When using the remote control, press the speed button to adjust the speed.


For children's safety, parents have to make sure their children are have good driving ability at high speed


Music Press the music button, the music will turn on. If not pressed back, then music will stop automatically

Mp3 Press the mode button on Mp3 (3-5 seconds), then activate bluetooth on cellphone

⚠ Don't put your ear too close, could cause hearing damage







1. The vehicle charging input socket is under the front of the seat, plug the charger port into the input socket
2. Plug the charger plug into the wall outlet as shown.
3. After 8 - 12 hours fully charged, unplug the charger plug from the wall outlet and unplug the charger port from the input socket on the vehicle

Maintenance For Your Vehicle

1. The vehicle material is made of polypropylene. use exposed to light direct sun or temperatures of -15 C are strictly prohibited. Vehicles must be kept away from hot objects, such as ovens and heaters, the plastic parts can melt.
2. Avoid operating the vehicle in wet or snowy conditions, and don't spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture on the motor or electric switch can corrodes and can cause buttons or motors to be damaged
3. Avoid operating the vehicle on sand, dirt or gravel, because it can causes the button or motor to fail.
4. The vehicle can be cleaned with a soft, dry cloth for good results
5. Do not modify the electrical system, when errors are found it must be addressed by professionals. Changes can cause fire resulting in injury serious and can damage the electrical system
6. Use for half a month, check whether the wheel rotates properly or not. Use lubricant to lubricate moving parts.

Troubleshooting & Solutions Guide

Problem: Vehicles cannot run

- Cause: The battery might not have any power after use and at least once a month, recharge the battery for 8-12 hours, **Don't charge for more than 18 hours**




Don't throw it in the fire. Batteries may explode or leak

Batteries with a lead acid seal must be recycled or disposed of in an environmentally friendly place

Warning :

1. This product is not a means of transportation, do not drive on the road, use this product under adult supervision.
2. Do not allow children under 36 months to use this product.
3. Overload is not allowed. maximum load 35 kg
4. The vehicle must be assembled and inspected by an adult,
5. Do not wash the product with water, wipe only with use a soft, damp cloth
6. Recharging the battery must be done by an adult, don't let children charge battery.
7. Driving is prohibited on public roads, downhill roads, pool sides, head of stairs and other dangerous areas.
8. Please read carefully and keep the user manual for your child's safety.
9. To prevent children from shortness of breath, keep the plastic from children
10. Only adults may operate the remote control, and keep a distance of up to 10 m for the remote controller and the vehicle.

Only adults may use the remote control



2.4G Remote control instrucktions
Step 1: The remote controller is loaded with AAA batteries
Step 2: Turn off the power switch on the vehicle.
Step 3: Hold down "▲"&"▼" keys for 3 seconds start match code, the frist LED flicker, now turn on vehicle power switch
the red indicaror light stop flashing and the code is successful.
key caption : "S" set up speed, 1 led lit up is low speed, 2 leds lit up is medium speed, 3 leds lir up is high speed, "▲"forward,"▼"back, "◀" left, "▶" right, press "P" key hold the brake, ALL LED flicker

Instructions: The vehicle is designed to operate at low speed only in reverse let the remote controller stop for 10 seconds it will trun off automatically repeat step 1 when you replace the remote controller battery