






















User Manual

Dog Crate Furniture














1
17
17
3
4
17
3
5
2
18
20
22
6
19
21
12
7
12
16
13
15
11
9
14
8
10

PART LIST

①  1PC	②  1PC	③  2PC	④  1PC	⑤  1PC
⑥  1PC	⑦  1PC	⑧  1PC	⑨  1PC	⑩  1PC
⑪  1PC	⑫  2PC	⑬  1PC	⑭  1PC	⑮  1PC
⑯  1PC	⑰  3PC	⑱  1PC	⑲  1PC	⑳  1PC
㉑  1PC	㉒  1PC			

HARDWARE LIST


A  M4*10mm 6PCS	B  5PCS	C  3PCS	D D1  Ø12*12mm 44PCS	D2  M6*35mm 44PCS
E  ST3.5*12mm 35PCS	F  M6*25mm 10PCS	G  M6*30mm 4PCS	H  3PCS	I  3PCS
J  J1 1PCS  J2 1PCS	K  K1 2PCS  K2 2PCS  K3 2PCS			
 CL 1PCS  DL 1PCS  DR 1PCS  CR 1PCS	N  2PCS			

HARDWARE SPARE LIST


A  M4*10mm 1PCS	D D1  Ø12*12mm 5PCS	D2  M6*35mm 5PCS	E  ST3.5*12mm 4PCS	F  M6*25mm 1PCS
G  M6*30mm 1PCS				


IMPORTANT


Two people are recommended to assemble and move this crate.
Ensure no parts are missing or damaged before assembly.



Cam Bolt Installation Procedure








STEPS


STEP-1

	D2 x 8 PCS




STEP-2

	E x 2 PCS
	CL x 1 PCS




STEPS

STEP-3 D2 x 10 PCS




STEP-4 D1 x 8 PCS



STEPS

STEP-5


D1 x 10 PCS




STEP-6

D2 x 2 PCS

Flip It Over






STEPS


STEP-7

F x 2 PCS



STEP-8


F x 2 PCS



STEPS


STEP-9

	G x 2 PCS




STEP-10

	E x 2 PCS
	K2 x 1 PCS




STEP-11

	D1 x 2 PCS




STEP-12

	F x 2 PCS
	G x 2 PCS




STEP-13

	E x 2 PCS
	D2 x 2 PCS
	K2 x 1 PCS




STEP-14

	F x 4 PCS
	D1 x 2 PCS




STEP-15




STEP-16

	E x 2 PCS
	D2 x 6 PCS
	CR x 1 PCS




STEP-17

D1 x 6 PCS




STEP-18

D2 x 6 PCS




STEP-19

D1 x 6 PCS




STEP-20




STEP-21

	C1 x 3 PCS
	D2 x 8 PCS




STEP-22

	D1 x 8 PCS




STEP-23

	B x 3 PCS
	C2 x 3 PCS
	E x 3 PCS
	H x 3 PCS
	I x 3 PCS




STEP-24




STEP-25

	A x 6 PCS




STEP-26

	E x 4 PCS
	N x 2 PCS




STEP-27

E x 8 PCS




STEP-28

B x 1 PCS




STEP-29

	E x 4 PCS
	K1 x 2 PCS




STEP-30

	D1 x 2 PCS
	D2 x 2 PCS




STEP-31

	E x 4 PCS
	K3 x 2 PCS




STEP-32

	E x 4 PCS
	DL x 1 PCS
	DR x 1 PCS



STEP-33

B x 1 PCS



STEP-34

