Solid Wood Desk Installation Guide





After opening the package, please find the following parts.

Step 1: After turning the two cabinets over, you can see the pre-drilled holes. Tighten the feet and secure them to the bottom of the cabinets to complete the installation.



Image 1

Step 2: Align the baffle with the pre-drilled holes on the two cabinets, then secure it with the long screws. After assembly,see Image 1.

Step 3: Remove the first drawer from the smaller side cabinet, place the tabletop on top of the two cabinets, align the holes, and secure it with screws. The tabletop assembly is complete, as shown in Image 2.



Image 2

Step 4: Open the drawer, align the handle with the reserved hole on the drawer, and then fix the handle with screws.





Finally