
ASSEMBLY INSTRUCTION
ITEM:N715P243118
CANOPY



ASSEMBLY INSTRUCTION
ITEM:N715P243118

Please read this instruction manual carefully before attempting to install.



We recommend 2 or more people to install.



The expected assembly time is 0.5 h.



Not intended for use by children.



Keep away from fire or other heat sources.



We recommend wearing protective gloves.






Please follow the instruction manuals and use a pad to avoid damage during assembly.
Unpack and take out the canopy fabric and the frame storage bag. Other parts are packed in the frame storage bag, please take them out for further assembly.

Note: Please do not use a knife when unpacking to avoid cutting the product and parts accidentally.

ASSEMBLY INSTRUCTION
ITEM:N715P243118


Part List

N715P243118

1 Canopy Frame -1pc 	2 Canopy Top -1pc 
3 Roller Bag -1pc 	A Sidewall with Zipper -2pcs 
B Sidewall with Window -4pcs 	C Rope -6pcs 
D Stake -12pcs 	E Sand Bag -4pcs 


ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 01




ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 02




ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 03




ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 04



ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 05



ASSEMBLY INSTRUCTION
ITEM:N715P243118

STEP 06

