INSTRUCTION

INCLUDED IN THIS BOX

Unfinished Frame, Assembly Required

Infinity Frame x4



Support Bar x 1 (Only included in 46" x 24", 46" × 36", 46" × 46", 60" × 24", 60" x 36", 60" x 46", 72" x 24", 72" x 36", 72" x 46")

Support Bar x 2 (Only included in 60" x 60", 60" x 72" , 72" x 72")



Wall Mount x2



Wall Anchor x4



Screw x4



Torx Key x1



FRAME ASSEMBLY

STEP 1

Lay out frame pieces, make flat side downward & show channel facing upward.



Pull up buckles, interconnect frames & press down to lock.



STEP 2



Insert support bar with connecting piece upward onto other one, slide support bars with open state indication (dot towards bolt by default) upward into connected infinity frame in cross shape & tighten them 180° clockwisely with torx key.



Interconnect last frame piece as STEP 1 & 2.

Support Bar x 1

(Only included in 46" x 24", 46" × 36", 46" × 46", 60" × 24", 60" x 36", 60" x 46", 72" x 24", 72" x 36", 72" x 46")



Support Bar x 2

(Only included in 60" x 60", 60" x 72" , 72" x 72")



INSERT PRINT STEP 3



Lay your print over frame, artwork side up! Fold silicone edges down at one of corners (like pizza box) & press folded corner into channel of frame at corner. You should not be able to see any silicones once inserted.





Move to opposite corner & repeat (similar to fitted bed sheet). Insert two remaining corners.

HANGING STEP 4



1. Draw positioning point with wall mount where you would like to hang wall art.



2. Hammer wall anchors into positioning point.



3. Fasten screws into wall anchors to secure wall mount.

Hang your wall art on wall using its metal channel on back.

