ASSEMBLY INSTRUCTIONS

HYFP-003-HT

HYFP-003-W



Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.

		
Recommended installers:2	**Put a carpet on the floor before unpacking**	**Estimate installation time: 30minutes**

ASSEMBLY INSTRUCTIONS

PART LIST

Item no.	Reference Image	Qty
A		X1
B		X1
C		X1
D		X1
E		X1
F		X1
G		X1
H		X1
I		X1

Item no.	Reference Image	Qty
J		X1
K		X1
L		X1
M		X2
N		X1
O		X1
P		X1
Q		X1
R		X2

ASSEMBLY INSTRUCTIONS

HARDWARE LIST

Item no.	Reference Image	Qty
1	 Ø8*30mm	X34+3
2		X28+2
3		X28+2
4	 Ø4*38mm	X9+1
5		X4
6		X2
7	 Ø3*14mm	X36+3

Item no.	Reference Image	Qty
8	 Ø3*15mm	X41+4
9	 Ø3.5*10mm	X4
10		X8
11		X2
12	 Ø3*12mm	X8
13		X1

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

1







ASSEMBLY INSTRUCTIONS

2





ASSEMBLY INSTRUCTIONS

3







ASSEMBLY INSTRUCTIONS

4



③ 8PCS



① 8PCS



ASSEMBLY INSTRUCTIONS

5





ASSEMBLY INSTRUCTIONS

6





ASSEMBLY INSTRUCTIONS

7



①5PCS



③7PCS



ASSEMBLY INSTRUCTIONS

8





ASSEMBLY INSTRUCTIONS

9



Ⓜ 2PC



⑩ 8PCS





ASSEMBLY INSTRUCTIONS

10





ASSEMBLY INSTRUCTIONS

11



⑪ 2PCS



Ø3*14mm
⑦ 8PCS



Ø3*12mm
⑫ 8PCS



ASSEMBLY INSTRUCTIONS

12



Ø3.5*10mm
⑨ 4PCS



Ø3*14mm
⑦ 16PCS



ASSEMBLY INSTRUCTIONS

13



1



2



3

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS

14

Common Door Panel Issues:



Door panel is not straight

Adjust the door hinges



Finished





The gap between door panels is too large

Adjust the door hinges



The door panels are not coplanar

Adjust the door hinges



Finished





The two door panels are not at the same height

Adjust the door hinges



Finished



ASSEMBLY INSTRUCTIONS

15



⑬ 1set

A	B	C	D	E
				
1pcs	2pcs	Ø8*3/4" 1pcs	Ø8*1-1/2" 1pcs	1pcs

