
Furniouse

TV STAND


SKU:TS006




























Furniouse

www.furniouse.com

Exploded drawing



Parts

178*35.1*2.4  ①X1	177.2*35*2.4  ②X1	71.4*31.3*1.2  ③X1	20.9*29.1*1.2  ④X4	71.4*31.3*1.2 Parts  ⑤X1
47.6*17.8*1.2  ⑥X1	127.4*31.3*1.2  ⑦X1	128.2*23.1*0.3  ⑧X1	22.3*29.5*1.2  ⑨X2	91.8*4.1*1.2  ⑩X1
47.9*17.8*1.2  ⑪X1	71.4*31.3*1.2  ⑫X1	71.4*31.3*1.2  ⑬X1	177*5.8*1.5  ⑭X2	31.8*5.8*1.5  ⑮X4
25*14.5*1.2  ⑯X3	25*14.5*1.2  ⑰X3	36.8*14.5*1.2  ⑱X3	37.6*24.5*1.2  ⑲X3	70.8*23.5*1.8  ⑳X1
42.1*23.5*1.8  ㉑X1	42.1*23.5*1.8  ㉒X1	42.1*23.5*1.8  ㉓X1	70.8*23.5*1.8  ㉔X1	72.2*21.9*0.3  ㉕X2

Parts


HARDWARE


A x74 M6*35	**B** x74 M15*9.5	**C** x58 M6*30	**D** x44 M3*12	**E** x2 M7*40
F x2 M4*14	**G** x6 25*12*3	**H** x16	**I** x14 M3*16	**J** x14
K x30 M4*35	**L** x24 M4*14	**M** x4	**N** x2	**CL** x3
CR x3	**DL** x3	**DR** x3		

Cam lock Fastening System

This Cam Lock Fastening System will be used throughout the assembly process










Assembly Instructions


01






02









Assembly Instructions

03







B x8	C x6
 M15*9.5	 M6*30

04



WANRING:Kneeling and pressing the sheet on an uneven surface may cause the sheet to fracture




Rotate 180 degrees




x2

D x12	CL x2	CR x2
 M3*12		



Assembly Instructions


05




C x4	K x4
M6*30	M4*35

06

WANRING:Kneeling and pressing the sheet on an uneven surface may cause the sheet to fracture




A x8	D x6	CL x1	CR x1
M6*35	M3*12		




Assembly Instructions

07





08




Assembly Instructions

09










10


Rotate 180 degrees






Two person assembly








Assembly Instructions




11












12






Assembly Instructions

13







B x18	C x12
 M15*9.5	 M6*30

14

This step requires two people. Rotate the unit 90° and stand it on the ground as shown in the diagram, then install Panel No.25 and Panel No.8.




Two person assembly




Assembly Instructions


15



N	x2
F	x2
	M4*14
A	x12
	M6*35




16




B	x12	C	x12
	M15*9.5		M6*30


Assembly Instructions

17







18



Assembly Instructions


19





I x14	J x14
M3*16	

20




x3

K x12
M4*35


Assembly Instructions


21





x3


22














Assembly Instructions


23










D x6	DL x1	DR x1
M3*12		



24










A x4	B x4
M6*35	M15*9.5


Assembly Instructions

25














26














Assembly Instructions

27










D x6	DL x1	DR x1
M3*12		

28










Assembly Instructions

29











30


Pre-drilled hole at wall














Assembly Instructions


31






32










Assembly Instructions


33






Hinge Installation Instructions






To adjust the vertical height.
Loosen the four screws``A`` on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.
Loosen screw``B``and adjust door,if the door can not be adjusted,please loosen screw``C``,then try again.Tighten screw``B``and``C``.



To adjust side ways.
Turning the screw``C``on BOTH hinges on each door.