SL2522

Inflatable water park

Owner's manual
Ages: 3-12 years

200"X196"X100"
(508x498x254cm)
Approximate Size Inflated



⚠ CAUTION:ELECTRICALLY OPERATED PRODUCT
The blower is not recommended for children under 14 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

⚠ WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.
Do not use extension cords with this product. Outdoor use only.
Read all instructions before assembling this inflatable device. Keep instructions for future use.

⚠ WARNING:
ELECTROCUTION RISK:
- KEEP ALL ELECTRICAL LINES, RADIOS, SPEAKERS AND OTHER ELECTRICAL DEVICES AWAY FROM THE CONSTANT AIR INFLATABLE.
- DO NOT PLACE THE CONSTANT AIR INFLATABLE NEAR OR UNDER OVERHEAD ELECTRICAL LINES.

⚠ WARNING: CHOKING HAZARD- TOY CONTAINS A SMALL BALL.

⚠ WARNING



Children (especially toddlers) are at high risk of drowning. Closely watch children who are in or near this Inflatable device. Empty Inflatable device or prevent access when not in use.
Drowning Risk:
- Keep unsupervised children from accessing the pool by installing fencing or other approved barrier around all sides of the Water Park.
- State or local laws or codes may require fencing or other approved barriers. Check state or local laws and codes before setting up the Water Park.
- Drowning occurs silently and quickly. Assign an adult to supervise the Water Park
- Keep children in your direct sight when they are in or near the Water Park and when you are filling and emptying the Water Park.
- When searching for a missing child, check the pool first, even if you think your child is in the house.

First Aid :
- Keep a working phone and list of emergency numbers near the Water Park.
- Become certified in cardiopulmonary resuscitation (CPR) so you can respond to an emergency.

PART LIST


(A) 1 Inflatable Water Park


(B) 1 Blower


(C) 1 Carrying Bag


(D) 2 Blower Stakes


(E) 8 Water Park Stakes


(F) 4 Repair Patches


(G) 1 Hose Assembly Kit


(H) 1 Inflatable Basketball


(I) 4 Rings

SAFETY WARNINGS: ELECTRICAL BLOWER

RATED VOLTAGE RANGE:
MODEL NO.: Z-70
AC110V-120V, 60Hz, 7.08A

DANGER **CAUTION: ELECTRICALLY OPERATED PRODUCT**

DANGER - TO PREVENT ELECTRIC SHOCK, DO NOT IMMERSE IN WATER. WIPE CLEAN WITH DAMP CLOTH. WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH. ADULT SETUP AND SUPERVISION REQUIRED.

CAUTION: The blower is a high volume blower, and is capable of moving lots of air very quickly. Place the blower in an area where it will not suck in dirt or leaves. Keep away from water and traffic. Keep children away from the blower. Only the blower supplied should be used for infl ation

INSTRUCTIONS FOR BLOWER INSTALLATION

NOTE: Set up as close to power source as possible. The product should be periodically examined for potentially unsafe conditions such as: damaged cord, plug, housing or parts, and that in the event such damage is found, the product should not be used until properly repaired. Never leave the blower outside in the rain or exposed to the elements when not in use. When in use, do not place the cord across traffic areas, water or damp areas. The blower should be placed on a stable surface and anchored per product instructions. The power cord of the blower is equipped with a Ground Faulty Circuit Interrupter plug.

1) Make sure that the blower switch is in the "OFF" position. Plug the blower into a 110V-120V outlet.
2) Set the power switch of the blower to "ON" to inflate. After use, turn the power to "OFF".
3) To disconnect, have an adult grip it tightly and pull the plug from wall outlet.

⚠ WARNING: Failure to follow these instructions could result in serious injury or death.
- Cautionary statements which should be read before beginning assembly.
- **ADULT SET-UP AND SUPERVISION REQUIRED.**
- Use only with Ground Fault Circuit Interrupt receptacle.
- This blower is for residential use only. It is not intended to be used in commercial or industrial settings.
- Never insert fingers, pencils or any other object through the grill at ANY time.
- Do not operate blower with a damaged cord or plug, after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not operate in the presence of explosive and/or flammable fumes.
- Never connect the blower to any solid - state speed control device.
- To reduce the risk of fire or electric shock, do not use this blower with any solid-state speed control device.
- Always unplug the blower before servicing.
- Outdoor use only

⚠ WARNING
Electrocution Hazard- DO NOT USE EXTENSION CORDS WITH THIS PRODUCT.

INSTRUCTIONS FOR BLOWER CLEANING AND STORAGE

Do not immerse the blower in water. Unplug the blower before cleaning. To clean: wipe with a damp cloth. The blower does not require any lubrication and has no user serviceable parts. Do not attempt to service the blower. When not in use, store the blower indoors in adry place. Store the blower upright on a stable surface. Loosely coil the cord and place it beside the blower.

This blower is not a toy. Use under the direct supervision of a competent adult. Keep away from children.

⚠ SAFETY WARNINGS: SET UP

ADULT SUPERVISION AND SET UP REQUIRED. This product should be inflated or deflated only by a competent adult. Follow all instructions provided.
WARNING! Falls onto hard surfaces can result in head or other serious injuries.
Never place on concrete, asphalt, wood,packed earth, or other hard surfaces.
Carpet over hard floors may not prevent injury.

⚠ • **WARNING! Only for domestic use.** Intended for outdoor domestic family use only. Not for use in public areas or as a rental.
- Product is heavy. Use caution when lifting.
- Product should never be dragged across concrete, pavement or other rough surfaces.
- **WARNING!** Keep away from fire. Keep fabric clear of all flame and ignition sources.
- Do not set up in windy or rainy conditions: sudden gusts of wind may lift the product off of the ground.
- Product can be installed in any orientation in relation to the sun, since there are no metal components or surfaces that can absorb excessive solar radiation.
- Set-up in outdoor location only that meets the following criteria:
  - Place on level ground and firm grass or soil to allow proper use of stakes.
  - Placing on slanted or uneven surfaces may cause the product to tip.
  - Stakes should be placed at an angle for better anchorage, should be driven under the ground to prevent tripping.
  - Minimum clearance zones: Place at least 2m away from any other objects.
  - Objects to be avoided include but are not limited to fences, buildings, trees, overhead branches, laundry lines, electrical wires, walls, or bodies or sources of water.
  - Make sure the area around the product is secure by adding safety barriers, if necessary, to keep young children and pets from gaining access.
  Electrical cord must not be passed under the air filled devices (inflatable Water Park) and interfere with its operation.• The Water Park uses a main powered blower (air pump) to maintain pressure, only to be used by an adult.
- Only the blower supplied should be used for inflation.
- Do not use extension cords with this product. Set up as close to power source as possible. The blower should be securely anchored to the ground before use.
- CAUTION: the blower is capable of moving large volumes of air very quickly. Place the blower in an area where it will not draw in dirt or leaves. Keep blower and power cord away from children, water and traffic.
- ATTENTION: Blower should remain on and continuously inflate Water Park during use. Airflow through seams is normal
- Do not use the product if wind speed exceeds 30km/h.
- Do not consume food, drink and gum on this product.

Minimum Clearance Zones

MINIMUM CLEARANCE ZONES
Make sure that there is a 6.6ft(2m) obstacle-free zone around the product, including a fence, garage, house, overhanging branches, laundry lines or electrical wires.



SAFETY WARNINGS: FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.



- **Constant, competent adult supervision of children and other young users is required at all times.**
- **Keep the area around the product clean, and clear of objects, to prevent slips and falls.**
- **Instruct children on proper use of this product. Do not use in a manner other than intended.**
- **Helmets, headgear, shoes, glasses, loose clothing, scarves, hoods, or clothing containing drawstrings should not be worn when using this product.**
- **Do not allow other toys or objects inside the product.**
- **Instruct children not to attach items to the product that are not specifically designed for use with the equipment, such as but not limited to, jump ropes, clothesline, pet leashes, cables and chains as they may cause a strangulation hazard.**
- **Keep pets away from product.**
- **Bounce away from others and stay away from sides wall, especially the opening.**
- **Do not jump onto or off of product.**
- **Do not allow children to play together who are unevenly matched in weight and height.**
- **The Maximum fall height of the inflatable device is 127cm.**
- **Thoroughly dry before use.**
- **Total weight of children must not exceed 500lbs（225 kg）on slide and pool.**
- **Only one child at a time is allowed on each slide and climber.**
- **Children must not slide down head first on their stomach.**
- **Do not let children walk on the side where blower motor is attached.**
- **Always dry product before storage.**
- **Never use product as a floatation or life saving device.**
- **Children can drown in very small amounts of water .Empty the pool when not in use.**
- **Do not install the paddling pool over concrete,asphalt or any other hard surface.**
- **Always check product and all its anchorage points during use, and re-secure, as appropriate. Always check for excessive air loss, and re-inflate before allowing play to continue.**
- **As an outdoor product, this inflatable is subject to wear and deterioration. Keep product properly maintained and watch for signs of fabric failure. Weak or torn surfaces must be repaired promptly.**
- **If product contains a pool:**
  - Never dive or jump into the pool area.
  - Do not sit on the edges of the pool as flooding may occur.
  - Always drain product after use. Do not leave it inflated or full of water overnight.
- **Keep the pool area clean to prevent illness. Instruct all children never to drink pool water and to practice good hygiene.**
- **Before and during use, check for air loss. Check blower is properly connected.**
- **Always check the product and all its anchorage points before and during use, and to re-secure as appropriate.**
- **If applicable, remove water and debris from pocket steps after each play cycle.**
- **After inflation, the blower should run continuously while children are playing.**
- **Prior to deflating, remove all children.**
- **Always deflate product after use, and store indoors.**
  The product should be periodically examined for potentially unsafe conditions such as: damaged cord, plug, housing, or parts, and that in the event such damage is found, the product should not be used until properly repaired. Never leave the fan outside in the rain or elements when not in use. Refer to the instructions for set-up, storage, maintenance and care.
- **Product can be installed in any orientation in relation to the sun, since there are no metal components or surfaces that can absorb excessive solar radiation.**
- **To change the water of paddling pools frequently (particularly in hot weather) or when noticeably contaminated.**
- **Product can be installed in any orientation in relation to the sun, since there are no metal components or surfaces that can absorb excessive solar radiation.**

Water Park Placement



Designate a flat, level surface that allows for 2m of minimum clearance around the Water Park.
NOTE: DO NOT place the Water Park on a hard surface like asphalt, concrete or packed earth as both serious bodily injury and damage to the Water Park could result.
ASSEMBLY AREAS
- **Make sure the assembly area is flat and level and is free of rocks, sharp objects or other obstructions.**
- **Do not set up the Water Park on a slope or inline.**
- **Do not set up the Water Park on hard-packed earth, asphalt, decking or any hard surface as doing so may result in physical injury and/or damage to the Water Park.**
- **Once the Water Park is inflated or filled with water, do not attempt to drag it to another location.**
- **Check your local county or city regulations for requirements on securing the pool.**
- **Secure the pool from unauthorized use.**

Staking the Water Park

⚠**CAUTIONS: The Water Park and all its anchorage points should be checked before and during use. Reinflate or re-secure as appropriate. DO NOT let children play on the water park until it is fully inflated!**

1



Secure the Water park to the ground with the provided stakes. To prevent tripping,pull the stake loops all the way out, then drive stakes completely into the ground.

2



Secure the Blower to the ground with the provided stakes.

⚠ **WATER PARK CAUTIONS:**
- **Drive ground stakes completely into the ground to avoid tripping hazard.**
- **Do not use the Water slide until an Adult has assembled, staked down, and fully inflated.**
- **Do not set up or inflate the Water Park in windy and/or rainy conditions as wind gusts may cause the park to become unstable and possibly be lifted from the ground.**