Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.





- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.


TUFTED CLUB CHAIR



Part List


Label	Picture	Description	QTY
A		Chair Seat	1
B		Chair Backrest	1
C		Hind Leg	2
D		Front Leg	2

Hardware

Label	Picture	Description	QTY
①		Washer Ring	7

Assembly Preparation

Before Beginning Assembly :




A



B



C



D




x 7




- Read instructions, cover to cover-
- Have 2 adults on hand for assembly-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-

Assembly Steps

Overview



Step 1




Chair Seat (A)



Chair Backrest (B)



Hind Leg (C)




Front Legs (D)



① x 7


This Chair consists of multible parts and may take up to 30 minutes to assemble . The picture above provides an overview of the Chair parts to help you visualize and understand each component . Before you start assembling , please read through the instructions below to familiarize yourself with the parts and steps.

Step 2




With assistance from your adult partners,Position the Chair Seat(A)on its back on a clean, non-marring surface, as shown.Remove the four wooden legs from the backrest.

Step 3




Install the first Front Leg(D) into the bottom of the Chair Seat(A) by placing one Washer Ring(①) onto the threaded stem.
Insert the threaded stem of the Front Leg(D) into the front mounting position of the Chair Seat(A) then tighten by turning the leg clockwise until the leg is completely secure.
Repeat this process with the remaining three Legs.
Note: The use of the Washer Rings are OPTIONAL and are especially useful to help alleviate slight wobbles. **Some Legs may need more than one whilst some Legs may not need any.**

Step 4



Position yourself behind the chair. Place Chair Backrest(B)into theChair Seat(A).While tilting theChair Backrest(B) slightly forward. Then gently pull the Chair Backrest(B) towards you while pushing it down all the way into the Chair Seat (A)slot located to the rear of the Chair Seat(A). (as marked by the arrow above).

Step 5



Make sure all parts are connected and locked into position.
Turn the Chair right way up.
Your Chair is ready for use.
This Chair can only be used on a flat, level surface.