


Outdoor Convertible Bench




Outdoor Convertible Bench Assembly Manual



1400mm
340mm
695mm
325mm
782mm
438mm
1400mm
340mm
325mm
863mm




A 1X




B 1X




C 2X



D 1X



E 1X



F 2X



G 2X

M5*12



H 4X

M6*16



I 14X

M6




J 14X



K 14X


S4



L 1X


Important Installation & Safety Notes


1. Follow the installation steps in order.
Do not force assembly, as this may damage components.
2. Two people are required for mode conversion.
Applying force to only one side can cause parts to deform.
3. For outdoor use, regularly check and tighten all bolts to extend the product's service life.
4. Do not jump on or apply excessive weight to the chair, as this compromises structural safety.
5.The plastic cover (Part K) can be placed over the bolts after all assembly steps are completed.



Step 1: Install Cross Support Bars

Align 2 cross support bars (Part C) with pre-drilled holes on side frames A/B. Slide washer (Part J) onto M6*16 bolt (Part I), insert through holes and fully tighten. Afterwards, cover the bolts with plastic cover (Part K).





D 1X



M6*16

I 4X




M6

J 4X



K 4X





S4

L 1X

Step 2: Install the Fixed Base

Attach the faceplate (Part D) to the shorter side of components A/B. Flip A/B for easier alignment with pre–drilled holes. Slide washer (Part J) onto M6*16 bolt (Part I), insert through holes and fully tighten. Afterwards, cover the bolts with plastic cover (Part K).






E 1X


Step 3: Open the Hinge Latches

Take out the hinge assembly (Part E) and fully open the latches on both ends in preparation for the next installation step.






H 4X





J 1X

Step 4: Install the Adjustable Backrest

Align hinged panels (Part E) with frames A/B. Insert Part H (M5*12 screws) and tighten to complete assembly.







F 2X



G 2X



M6*16

I 2X




M6

J 2X




K 2X




S4

L 1X

Step 5: Install the Fixed Latches



Move to the back of the product for easier installation. Take the fixed latches (Part F), slide on Part G, Part J, and Part I (M6*16 bolts) in sequence. Align with the mounting holes on the side frames (Part A/B), then over the bolts with plastic cover (Part K).



Step 6: Convert to Chair Mode & Secure with Latches

Convert the tabletop from horizontal table mode to vertical backrest mode:

1. Press the hinge release buttons on both sides simultaneously, hold the tabletop and lower it slowly to switch to backrest mode;
2. After conversion, fasten the fixed latches (Part F) on both sides of the backrest to complete locking.