ASSEMBLY & INSTRUCTIONS
ECL3578

Please read carefully and save these instructions, as you may need them at a later date.

IMPORTANT SAFETY INSTRUCTIONS: This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

GENERAL

Remove the lamp and parts from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1.Firstly, Place Socket Assembly (B) onto Lamp Body(A),tighten securely.

2.Place Harp(C)onto Socket Assembly(B).

3. Put Shade(D) onto Harp(C) and tighten with Finial(E).

4. Make sure it does not exceed the maximum wattage specified on the lamp Wattage Rating Label.



1. LAMP BODY(A)
2. SOCKET ASSEMBLY(B)
3. HARP(C)
4. SHADE(D)
5. FINIAL(E)