
1.Mark the marked positions for installation.
2.Drill holes at marked positions and insert plastic wall plugs.
3.Install French cleats