
INSTRUCTION MANUAL

Floating TV Cabinet

MFLHKTS023



NOTE: If you order the Model with Fireplace. You will get Two Package and may arrived on different days. Please make sure that all packages are delivered before unpacking and assembling the product, if you have any questions, contact us ASAP.

NOTE: Please refer to the separate fireplace manual for installation instructions. This cabinet manual does not include fireplace installation details.

Wolfthontech1@gmail.com

Please choose SMS or email as your first choice for communicating with us.

WELCOME TO THE FUTURE OF HOME ENTERTAINMENT!

Thank you for choosing our new electric fireplace and TV stands! Our products are designed to be both stylish and functional, with a focus on energy efficiency and sustainability.

We use high-quality materials to ensure that our pieces are built last, so you can enjoy them for years. Whether you're looking for a cozy electric fireplace or a stylish TV stand, we have something for everyone.

Our products are perfect for any home or office, and we're confident that you'll love them as much as we do!

Wolfthontech1@gmail.com

NOTICE

1.Children are not allowed to operate
2. Faster installation is possible with power tools.
3. Do not pull the door vigorously to prevent the storage cabinet from tipping over.
4.Please attach the storage cabinet to the wall with an anti-tip device after installation is complete.
5. When using the storage cabinet for the first time,please keep it in a ventilated environment to allow the smell to fully evaporate.
6.When placing the partitions,please make sure the nails are firmlyinstalled to prevent the partitions from falling off.
7. If any parts are missing,broken,damaged or worn,discontinue use of the product until repairs are made and/or factory replacement parts are installed
8. Do not use this product in a manner inconsistent with the manufacturer's instructionsas this may void the product warranty
9.If accessories are missing, please contact customer service for communication in time, we provide 7x24 hours after-sales service
10.Do not use any attachments or accessories other than the original factory attachments and accessories
11.Do not alter this equipment. Any alteration will create a safety hazard.

BEFORE YOU START

⚠ Please read all instructions carefully.
⚠ Retain instructions for future reference.
⚠ Separate and count all parts and hardware.
⚠ Read through each step carefully and follow the proper order.
⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product un-necessarily once assembled.
⚠ Always place the product on a fiat, steady and stable surface.
⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

PRE-INSTALLATION

GRAB YOUR TOOLS


Phillips Screwdriver

2 Persons Assembly

Up to 60 Minutes For Assembly


WHAT'S IN THE BOX

1




1PC

2




1PC

3




2PCS

4




1PC

5




1PC

6




1PC

7




1PC

8




2PCS

9




1PC

10




1PC

11




1PC

12




1PC

13




1PC

14




1PC

15



1PC


16



1PC

HARDWARE

A



34+2PCS

B



34+2PCS

C



Φ6*30mm 48+2PCS

D




Φ4*35mm 20PCS

E




Φ4*25mm 4PCS

F




Φ4*30mm 8PCS

G




8PCS

H




Φ4*50mm 8PCS

I



4PCS


J



Φ4*14mm 24PCS

PRE-ASSEMBLY PREPARATION

Ensure all parts and hardware are included in the package.
Lay out all components on a fiat, soft surface to avoid scratches.




NOTE: If you have ordered the model WITH FIREPLACE

PRODUCT ASSEMBLY

STEP 1


	A x 2PCS
	E x 2PCS
	F x 4PCS



Please put board 1
Rotate 180°

STEP 2

	A x 2PCS
	E x 2PCS
	F x 4PCS




Please put board 2
Rotate 180°

PRODUCT ASSEMBLY

STEP 3

C x 4PCS


D x 8PCS



STEP 4

B x 4PCS


C x 4PCS



PRODUCT ASSEMBLY

STEP 5





STEP 6






PRODUCT ASSEMBLY

STEP 7


C x 12PCS

D x 12PCS



STEP 8

A x 14PCS




PRODUCT ASSEMBLY

STEP 9

B x 14PCS


C x 15PCS



NOTE: For Model WITHOUT a Fireplace,If you have purchased the TV stand model without a fireplace, please skip STEP 10-14 and proceed directly to STEP 15.

STEP 10

A x 4PCS





PRODUCT ASSEMBLY

STEP 11

B x 4PCS


C x 3PCS





STEP 12

A x 8PCS





PRODUCT ASSEMBLY

STEP 13


B x 8PCS

C x 6PCS






STEP 14




PRODUCT ASSEMBLY

NOTE: For model **WITHOUT** a fireplace, please continue with Step 15 below.

STEP 15



	G x 8PCS
	H x 8PCS




PRODUCT ASSEMBLY

STEP 16


I x 8PCS

J x 6PCS




STEP 17

J x 16PCS




PRODUCT ASSEMBLY

ADJUSTING DOORS / AJUSTEMENT DES PORTES



First, install one pair of part I onto ⑮. Then install part ⑮onto part ⑩.
When attaching doors, first secure the four screws in the oval holes of part I (these align with the four small holes on part ⑩). Close the door to check if its position is correct. If not, adjust the position according to the diagram. Once adjusted, tighten the four screws in the round holes of part I.

PRODUCT ASSEMBLY



Final Check

1. Ensure all screws are tightened.
2. Verify that all panels are securely fitted.
3. Clean any dust or debris from the assembly process.

Your TV stand is now successfully assembled and ready for use! We hope you enjoy your new TV stand! If you're happy with the result, we'd love to see how it looks in your space. Share a photo of your setup and inspire others with your creativity. Your experience help us continue improving our products!

HELP CENTER

Question about your product? We're here to help. Visit us at:



Chat Support


Product inquiry



Orders FAQ


Product Assembly



Returns & Refunds

WE STAND BEHIND THE QUALITY OF OUR FURNITURE

1. If you have any issues with your item, please let us know! We will always do our best to come up with a solution that you will be happy with.
2. Please get in touch with our customer service team before returning the product.
3. And please do not throw away the original box(es) if you have not finished assembling and confirmed no quality issues.

Length of return period:
You can return items within 30 days of purchase
In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:
1. Your item has a manufacturing defect in materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after you send us photos or videos of the defect.
2. Your item has been damaged in transit. For example, glass is broken or product is damaged. We will send you a prepaid shipping label after you send us photos of the damage.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after you send us photos of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

* However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

1.You don't like the product(s) after receiving the box(es).
2.You no longer need the product(s) but have received the box(es).
3.You buy the product(s) by mistake but have received the box(es).
4.Order/shipment cancellation failed, and you have received the box(es).

Return Request

In order to get a full refund as described in this return policy, all items must be:

1.In a brand new/unused condition. Please provide photos before and after packaging.
2.When returning, all accessories and parts must be firmly packed in all original packaging. If your return does not meet these requirements, you may not receive a full refund.

When will I be refunded?

The refund is issued once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us via email, and we will work on a solution to ensure your satisfaction.

AFTER SALES SERVICE

If any problem occurs, you can check the manual for troubleshooting indetail, or contact to our customer service on Amazon.

To contact authorized Amazon seller, please following steps:

Step1	Go to Your Orders. Find your order in the list.
Step2	Click “Ask a question". (Or go to the product detailpage, select the name of the seller.On the next page, select "Ask a Question").
Step3	Select the product and tap “Other" options in theSeller Messaging Assistant chat.
Step4	Send the message to us for after-sales support.

We always work hard to serve you and provide you a better customerexperience.
Customer service:

Customer service: Wolfthontech1@gmail.com

Please attach follow purchase infor in the message:

Order ID:

Model:

Purchase Date:

Buyer Name:

Please feel free to send us the text or email. We will reply to you within 24 hours. Also please feel free to contact us if you have received the defective items.

SAVE THESE INSTRUCTIONS