VEVOR

Upgrade · The Home Creator Way

SHAMPOO SINK

Model：WL-U5610I/WL-U5610II/WL-U5610III


VEVOR
Support Center

WL-U5610I **WL-U5610II** **WL-U5610III**

VEVOR
Upgrade·The Home Creator Way

SHAMPOO SINK

Model：WL-U5610I/WL-U5610II/WL-U5610III



	WL-U5610I	US	
	WL-U5610II	EU	
	WL-U5610III	AU	

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

INSTRUCTIONS


Thank you very much for choosing this product. Please read all the instructions before using it. The information will help you achieve the best possible results.
PLEASE NOTE! Drawings in this manual are for illustration purposes only and in some details may differ from the actual product.
The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
Please place in a position that children cannot climb or move, so that the product does not fall over and injure children.
USAGE SAFETY
1. Select an area for assembly that is clean and free of any debris that might cause persons working on the assembly to trip.
2. Do not lift heavy parts or assemblies. Use crane, jack, tackle, fork trucks or other mechanical devices.
3. Preview the assembly instructions in your operator's manual before proceeding further.
4. After completing assembly, thoroughly inspect the machine to be sure that all nuts, bolts or any other fastener assemblies have been thoroughly tightened.
5. This product is not a toy or a washing vessel and should not be used for any purpose other than a shampooer.
6. The drainage pipe of the product, please use the clamp firmly connected to avoid water leakage. The other end of the drain pipe should be placed in the household drain sink or drain pipe, and remember that the end accessories of the drain pipe should not be placed with electrify things to avoid electric shock.
7. Avoid to use any hard objects or any chemicals which can dissolve plastic to clean the basin.
8. Please put the product in a flat place for use. When using the product on sloping or uneven ground, there is a risk of rollover during use.

SAVE THESE INSTRUCTIONS




TECHNICAL PARAMETERS

Model	WL-U5610I	US	AC100V~120V ~ /60HZ, 35W	
	WL-U5610II	EU	AC220~240V ~ /50HZ, 35W	
	WL-U5610III	AU	AC220~240V ~ /50HZ, 35W	
Colour	Black			
Product size (mm)	510*520*(900-1270)			

Feature and Specification




Part List

Parts Code	Image	Parts Name	Qty(Pcs)
A		Basin	1
B		Water Stopper	1
C		Basin Bottom Bracket	1
D		Angle adjuster	1
E		Lifting Rod	1
F		Locking Device	1
G		Shower head Holder	1
H		Hose	1
I		Shower head	2
J		Drain hose	1
K		Bucket hoop	1
L		Base	1
M		Water Bucket(9L)	2
N		Power	1
O		Foot control	1
P		Water pump	1
Q		Casters	4
R		M8 nut	4


Hardware List


Parts Code	Image	Parts Name	Qty(Pcs)
①		M6*25 Screw	4
②		Sleeve	4
③		M6*10 Screw	1
④		Spring washer	1
⑤		M8 Washer	1
⑥		Rubber gasket (already fixed on part G)	2
⑦		Locking Device (already fixed on lifting rod)	1
⑧		Locking Device	1
⑨		M8*35 Bolt	2
⑩		Filter	1
⑪		Assembly Tools	1

Assembly



Step 1
D 1PC
C 1PC
④ 1PC
⑨ 1PC
D
C
④
⑨
Step 2
A 1PC
G 1PC
⑥ 2PC
Rubber gasket
A
G
Rubber gasket
⑥


Step 3







Step 4







Step 5










Step 6
















Step 7
⑨ 1PC
⑤ 1PC
E
⑤
⑨
Step 8
A 1PC
E 1PC
A
E
L


Step 9
③ 1PC
A
E
⑪
③
L
Step10
B 1PC
I 2PC
H 1PC
I
H
B


Step 11




Step 12




Step 13



Step 14



Connections





Trouble and Solution

N0.	Trouble	Solution
1	Basin tilts forward	Please check Assembly Step 1 & Step 3 to make sure thedirections of A and C are correct as showing
2	Shower doesn't work	a.Please fill in clean water before using, water pump must putin clean water bucket, carefully check Assembly step 12 &step 13 to make sure all connected correctlyb. Make sure the foot control well connected to switch andstep on foot control to spray water
3	Water outlet pipe leaking	Make sure the locking device tightened well as Assembly step 4

Attention

1.Avoid to use any hard objects or any chemicals which can dissolve plastic to cleanthe basin.
2.Keep away any plastic packing from children to avoid danger of suffocation, do notuse the packing in cribs, beds, carriages, this plastic is not a toy.

