Installation Instructions

1. Use accessory screws to lock and fix the light fixture to the wall.
2. Use a lamp holder ring to lock and fix the lampshade onto the lamp holder
3. Install the light source on the lamp head.
4. Connect the plug wire of the lighting fixture to the power supply

Mounting the Chain:
Choose a secure location to hang the lamp (ceiling hook or beam).
Attach the chain using the hook provided.
Adjust chain length as desired.

Installing the Bulb:
Screw the bulb into the lamp socket.

Safety Instructions
Do not use in extreme weather or heavy rain unless in a covered outdoor area.
Avoid direct water contact with lamp or electrical components.
Disconnect power before changing bulbs.
Keep away from children when installed or operating.

Maintenance & Care
Clean the lampshades gently with a dry or slightly damp cloth.
Do not use harsh chemicals or abrasive cleaners.