01

Our sofa will be delivered to you.



02

Open the package.



03

Take out the sofa wrapped in a nylon bag.



04

Unzip to open the bag.



05

Please refrain from using scissors or knives to open packages to avoid damaging the contents or injuring yourself.



06

Carefully open the compression bag.



07

Vigorously beating the sofa and placing it in the sunlight helps the sofa regain its original shape.



08

If there are wrinkles, you can use an iron to smooth them out.



TIPS:

Our frameless foam and spring sofa bodies are designed with industry-leading technology from the consumer goods sector and can restore more than 90% of their original state after **72 hours to 1 week** of decompression, so customers need to be patient. Minor wrinkles and bends are common occurrences and do not indicate quality issues.