ASSEMBLY INSTRUCTION



Please follow the instructions listed below.

1. Unpack all parts from the carton carefully.
2. Thread the pole (A) clockwise to the socket(D)
3. Thread the pole (B) clockwise to the socket(D)
4. Thread the pole (C) clockwise to the socket(D)
5. Fix the harp (F) onto the saddle.
6. Place the shade (G) onto the harp (F)and screw the finial (H) onto the harp to secure the shade.
7. This lamp uses a 3-way Type "A" 100 watt bulb not included.

Important safety instruction:
This table lamp has a polarized plug (one blade is wider than the other).As a safety feature to reduce the risk of electric shock.This plug will fit in a polarized outlet only one way.If the plug does fit fully in the outlet,reverse the plug.If it is still does not fit.Contact a qualified electrician,never use with an extension cord unless plug can be fully inserted.Do not alter the plug.

Instructionsde Securitelmportants:
Cette lampe portative aune fiche polariss (unelame est plus large que I'autre) comme fonction desecurite afin de reduirele risque de choe electrique.Cette fiche entrera cans une prise de couran,polarisee dans une seule,direction.Si la fiche n'e.tre pas completement dans la prise inversez lafiche.Si cela ne fonctionne toujours pas.Contactez un electricien agree N'utillisez jamais derallonge a moins qus lafiche ne soit inseree entierement Ne modifiez pas la fiche.

CAUTION: TO REDUCE THE RISK OF FIRE USE MAXIMUM 100 WATT TYPE A BULB.