

No.
23114/15/16
& 24416

Curva
Trend Floor Lamp



LSE Retail Group
0161 832 4957
M44 5GR

CONTENTS



x1




x1


220-240V~50Hz
MAX 60W E27

ASSEMBLY


1.




2.



3.



4.



5.



CAUTION

Read all safety instructions carefully and keep for future use.

Failure to comply with the following safety instructions may cause electric shock, fire and/or serious injury

ELECTRICAL SAFETY

- Before commencing any work ensure the supply is switched off at the mains. Either by switching off the main switch at the consumer unit or by removing the appropriate fuse.
- This is a Class II product does not require an Earth connection 220 – 240V ~ 50Hz
- This fitting must be permanently wired into the electric system
- Do not modify or alter any product before or after installation. This will invalidate your warranty and may render the product un-safe.
- Before inserting and replacing bulb(s) make sure that the power is switched off and the bulb(s) have cooled down.

IF AT ALL UNSURE, STOP NOW AND SEEK PROFESSIONAL GUIDANCE

POSITION:

- For indoor use only
- Ensure there is a sufficient power supply and access to the fitting to enable safe maintenance

ASSEMBLY AND SET-UP:

- Working from the top of the floor lamp, screw the poles in to secure. (DIA.1)
- Insert the bottom pole into the base of the floor lamp. Use the wrench tool provided to secure into place. (DIA.2)
- Attach the shade over the lamp holder. Attach the shade ring over and screw in to secure. (DIA3)
- Insert the bulb (Not provided, do not exceed the wattage on the lamp holder).
- Insert plug into mains. DIA.4)
- Use the floor switch to turn on/off the floor lamp. (DIA.5)

AFTERCARE AND MAINTANENCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.