ASSEMBLY INSTRUCTION

Ax1



Bx1



Cx1



Dx4

Ex1

❶



❷



❸



❹