Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Table Top(A) for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

ASSEMBLY INSTRUCTIONS

ITEM NO.N715P549208

Dining Table



ASSEMBLY INSTRUCTIONS

ITEM NO.N715P549208

Please read these instructions fully before starting assembly：

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.

2. Kindly follow the assembly instructions step by step.

3. Do not tighten all screws and bolts until the table is fully assembled.

4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.


5. Parts of the assembly will be easier with 2 people.

Care and maintenance：

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTIONS








ITEM NO.N715P549208



ASSEMBLY INSTRUCTIONS

ITEM NO.N715P549208





Part List

A 	B 
TABLE TOP BETWEEN (1pc)	TABLE TOP SIDE (1pc)
C 	D 
PANEL TOP LEG (1pc)	FRONT LEG (2pcs)
E 	F 
BACK LEG (2pcs)	TOP STRETCHER (1pc)
G 	
BOTTOM STRETCHER (1pc)	

ASSEMBLY INSTRUCTIONS

ITEM NO.N715P549208


Hardware List

①  Ø 5/16" x 25 mm	②  Ø 5/16" x 35 mm
BOLT (2+1 pcs)	BOLT (16+1 pcs)
③  Ø 5/16" x 45 mm	④  Ø5/16" x 13 mm
BOLT (8+1 pcs)	LOCK WASHER (26+1 pcs)
⑤  Ø5/16" x 19 x 2 mm	⑥  4 mm
FLAT WASHER (16+1 pcs)	ALLEN KEY (1 pc)

ASSEMBLY INSTRUCTIONS


ITEM NO.N715P549208

STEP 1:



BOLT	LOCK WASHER	ALLEN KEY
Ø 5/16" x 25 mm	Ø5/16" x 13 mm	4 mm
①x 2	④x 2	⑥x 1

STEP 2:




BOLT	LOCK WASHER	ALLEN KEY
Ø 5/16" x 45 mm	Ø5/16" x 13 mm	4 mm
③x 8	④x 8	⑥x 1

ASSEMBLY INSTRUCTIONS


ITEM NO.N715P549208

STEP 3:



BOLT Ø 5/16" x 35 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16"x19x2mm	ALLEN KEY 4 mm
②x 8	④x 8	⑤x 8	⑥x 1

STEP 4:





BOLT Ø 5/16" x 35 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16"x19x2mm	ALLEN KEY 4 mm
②x 8	④x 8	⑤x 8	⑥x 1

ASSEMBLY INSTRUCTIONS

ITEM NO.N715P549208

STEP 5:





COMPLETE

