Outdoor Christmas Tree



AFTER-SALES SERVICE

If the item received is damaged, Missing of the accessory, Difficult to install, Or just you don't like it. Please contact us by email. We are always ready to service you and help you.

FCC WARNING STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1.Reorient or relocate the receiving antenna.

2.Increase the separation between the equipment and receiver.

3.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4.Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

PART LIST

This manual covers 12.8FT, 16FT, and 20FT models. Follow the steps for your purchased size.

Note: Some parts and steps apply only to specific sizes. Read all instructions carefully before installation.

Part		12.8FT QTY	16FT QTY	20FT QTY
A		5	6	7
B		1	1	1
C		1	2	3
D		1		
E		1	1	1
E-1			3	3
F		1	1	1
G		1	1	1
H		1	1	1
I		30	36	42
J		3	3	3
K		1	1	1

POWER TEST BEFORE ASSEMBLY

Connect the light strips to the power source as shown in the wiring diagram, plug in, and verify that the lights turn on. After confirmation, disconnect power before starting frame assembly.

If the lights do not work even after all connections are secure, do not disassemble or repair by yourself. Please contact our customer service immediately for assistance.



1 For installation, please choose a flat grassy area.

2 Screw [B] into the ground with tool [K].



3 Connect all [A] pieces into a ring.



4 Attach [E] to [B], then use [J] to secure the three legs of [E] to [A].



1

Adjust knob on [E] to stabilize.

2 

For 16FT/20FT only Connect [E] and [E-1].

3 

Hammer [J] into ground until secure.

5 Attach the poles, lamp panel, and star topper in sequence, and connect the wires between them.



Follow the assembly sequence for your model.

For 12.8FT only

[B]--[E]--[C]--[D]--[F]--[G]--[H]

For 16FT/20FT only

[B]--[E]--[C]--[F]--[G]--[H]

1 

Assemble the star topper.

2 

Fix strips into [A] with [I].