
Installation Manual




Stainless Steel Work Table









Customer Service: ahomrt@163.com

Parts List

1. Prior to assembly, separate and count all parts and hardware and identify all the parts as listed are received.
2. Please read the instructions manual before installation and follow the steps carefully as shown in the diagrams.

A M8x65  X4	B M8x30  X8	C M8  X12	D  X1
E  X12	F M8x10  X20	G M8  X1	Glove  X1

1  X1	2  X2	3  X1	4  X4
5  X2	6  X4	7  X4	8  X4

ATTENTION


1. 2 persons are recommended to assemble it. Power tools are highly recommended for screwing.

2.Please wear protective gloves when assemble for safety.


3. We value your experience, so whenever you encounter any issues (whether it's related to delivery, assembly, usage, or post-purchase care, etc.), please contact us promptly.

4.Please keep your children away until the installation is complete. This product contains small parts that could pose a choking hazard if swallowed.


STEP 1




Assemble four stainless steel table leg parts 4 onto stainless steel panel 1 at the positions shown in the drawing using screw E and metal washer F.



STEP 2





(1) As shown in the drawing, align the holes of metal parts 8 with the holes on stainless steel table leg parts 4.
Pass screw A through parts 8, stainless steel table leg parts 4 and stainless steel plate parts 3,
then tighten with nut C
(2)Install casters 7 onto table leg parts 4 as shown in the drawing. Make sure to tighten them fully..




Note: Stainless steel plate parts 3
has four adjustable height positions,
and it can be installed at the required height.

STEP 3







Assemble side panel parts 5 and parts 2 at the position shown in the drawing using screw B and nut C.




STEP 4




As shown in the drawing, secure side panel parts 5 to panel 1 with screw F.




STEP 5



The hook 6 can be hung on side panel parts 5 at your desired position for use.





Final Assembly