



ASSEMBLY INSTRUCTIONS







Notice:





1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.

		
Recommended installers:2	**Put a carpet on the floor before unpacking**	**Estimate installation time: 30minutes**

ASSEMBLY INSTRUCTIONS







PART LIST




Item no.	Reference Image	Qty
A		X1
B		X1
C		X1
D		X1

Item no.	Reference Image	Qty
E		X1
F		X2
G		X4
H		X1


ASSEMBLY INSTRUCTIONS

HARDWARE LIST

Item no.	Reference Image	Qty
1	 Ø8*30mm	X8
2		X8
3		X8
4	 Ø1/4"*2"	X8
5		X8
6		X8
7		X4


Item no.	Reference Image	Qty
8	 Ø3*14mm	X24+2
9	 Ø3*15mm	X17+1
10	 Ø10*3mm	X2
11		X4
12		X1
13		X1


ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1










ASSEMBLY INSTRUCTIONS

2










ASSEMBLY INSTRUCTIONS

3








ASSEMBLY INSTRUCTIONS


4




Ⓔ 1PC




⑪ 4PCS






ASSEMBLY INSTRUCTIONS

5



Ⓕ 2PC



⑦ 4PCS




Ø10*3mm

⑩ 2PC




Ø3*14mm

⑧ 24PCS




ASSEMBLY INSTRUCTIONS


6



1



2



3

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


7

Common Door Panel Issues:





Door panel is not straight

Adjust the door hinges




Finished






The gap between door panels is too large

Adjust the door hinges





The door panels are not coplanar

Adjust the door hinges




Finished






The two door panels are not at the same height

Adjust the door hinges



Finished








ASSEMBLY INSTRUCTIONS

8



⑬ 1set

A	B	C	D	E
				
1pcs	2pcs	Ø8*3/4" 1pcs	Ø8*1-1/2" 1pcs	1pcs

