ASSEMBLY INSTRUCTIONS FOR SOLID WOOD ROCKING CHAIR



Check Components:
1 mesh fabric,
2 side iron frames,
2 Solid wooden Armrest,
3 crossbar.
6 short screws are used to fix the crossbar.
4 iron screws are used to fix the solid wood handrail.
2 pieces of solid wood planks.



Use brass screws to install the solid wood armrest



Use long black screws to install side iron frame



Attach mesh fabric to the two corresponding crossbars



Use long black screws to install the other iron frame



Complete assembly. Place the soft cushion on the chair

ASSEMBLY INSTRUCTIONS FOR FOOTREST



Check Components:
1 soft cushion,
1 mesh fabric,
2 side iron frames,
4 crossbar,
8 screws to install crossbars



Use yellow screws to install one side iron frame



Attach mesh fabric to the two corresponding crossbars



Use screws to install the other iron frame



Complete assembly. Place the soft cushion on the footrest