# Assembly Instructions



A (Right and Left side frame): 2 pcs

B (Front and Back tubing): 2 pcs



C (Bottom Panel): 1 pc

D (Long Ladder): 2 pcs



E (Middle Stand): 1 pc



F (Perch Support Bar): 1 pc
(Top Perch): 1 pc
(Sunk Screw): 2 pcs

G (Toy Tubing): 1 pc



H (Side Tubing): 2 pcs



J (Right and Left seed-guard): 2 pcs

I (Front and Back seed-guard): 2 pcs



K (Swing): 1 pc

L (Toy Hook): 1 pc



M (Plastic Tray): 1 pc

N (Cup and Cup holder):2 sets

O (Arch ladder): 1 pc

P (Nut): 8 pcs

Q (Short Screw): 12 pcs

R (Long Screw): 12 pcs

S (Rolling Caster): 4 pcs




Step 1:

(1) Assemble part A and B, secure with 4 long screws;

(2) Put part C as shown.

(3) Insert 4 Rolling Casters as shown.




Step 2:

(1) Insert part H into holes provided in A, and connect with part E, F and G, then secure with long screws. Note: If you want to replace the Top Perch from part F sometime, then just release the sunk screws for replacement.

(2) Assemble part D, and secure with nuts.




Step 3:

(1) Assemble 4 seed-guards, and secure with P and Q as shown.

(2) Insert L, and secure with the butterfly screws provided in part F.




Step 4:

Put part K, O, N, and M as shown.

Now, your new stand is ready for use.