ASSEMBLY INSTRUCTIONS

Description: Pendant - Dark Antique Brass

These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this Pendant.

We strongly suggest that all hard wired fixtures be installed by a professional electrician.

***Parts Included*:**

1. Main body
2. Metal Shade
3. Mounting Spider
4. Canopy set

Hardware Enclosed:

1. (2) Mounting Screws
2. (2) Plastic Wire Connectors
3. (1) Green ground screw

To Install You Will Need:

1. 2 people recommended
2. Phillips Screwdriver (Not Provided)
3. Electrical tape (Not Provided)
4. Wire cutters (Not Provided)

To Assemble:

1. Carefully take out all fixture parts and hardware and lay them out on a clear workspace.
2. Remove all the packing **EXCEPT** packing on the rim part of the main body
3. Pass the Canopy & chain part through the metal shade.
4. Chain length can be adjusted from canopy side with the help of provided Quick Link with chain. Extra chain will hang there only or can be cut off above the Quick link making sure the pendant does not hang on an open link.
5. Shut off the main electrical supply from the main fuse box/circuit breaker.
6. Gently pull wiring down from ceiling junction box and allow to hang.
7. Open/ unscrew the bush just below the canopy.
8. Remove mounting spider from the canopy by unscrewing the collar. Let the Canopy fall down.
9. Then you will find Mounting Spider/ Centre nipple/ bush in correct position.
10. Align holes in mounting spider with holes in junction box and attach with two mounting screws. Secure screws with a Phillips screwdriver.
11. Carefully inspect pendant's fixture wires.
    Neutral fixture wire: White
    Hot fixture wire: Black
    Ground wire: Green
12. Attach the Ground wire from the pendant to the Ground junction box wire (usually Green). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.
13. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.
14. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.
    DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
15. Then push the canopy to the mounting spider & attach the 4 screw back & also screw the bush back to complete the electrical assembly.
16. Insert 01TypeA 60W bulbs into the socket. DO NOT EXCEED SPECIFIED WATTAGE.
17. Now, remove the packing on the rim part of the main body to complete the installation.
18. Restore power to junction box and test fixture. DO NOT EXCEED SPECIFIED WATTAGE OF PENDANT.

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.