Owner Manual



Thank you for your purchase

Send your order number to our after-sales service to get

① One-year warranty provided

② Whether satisfied or not, please contact us so we can make improvements and ensure your optimal experience.

③ Consultation on product installation and usage

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Warm tips:

1. Please check if the wire is connected correctly, do not press the wire under the lift chair base to avoid wear and tear.
2. You can untie the semi-transparent white bundling strap to extend the length of the wire.
3. Do not forcefully pull the wire connection point to avoid poor contact and short circuit.

Warranty Information

We have a limited 1 year manufacturer warranty against defect or damage. Normal wear and tear and consumer misuse would not be covered in this warranty. The furniture is warranted against defects in workmanship and materials. Items covered would be seam slippage, frame structural integrity, fit and finish of parts. Items not covered would be product abused by the user, normal wear and tear, stains or discoloration due to use, damage in any transportation. Softening of foam is considered normal wear and tear and is not covered by warranty.Warranty is for PARTS ONLY and does not include transportation and labor costs associated with any warranty claim.

Read Before Beginning Assembly

If you need help, please contact us

●Work in a spacious area and near where the unit will be used, preferably on a carpet, or use a piece of the cardboard packaging to protect your floor and product.
●Recommended # of people needed for assembly: 2 (however it is always better to have an extra hand). Estimated assembly time is 15min.
●Make sure all parts are included. Most parts are labeled or stamped on the raw edge.
●Read each step carefully. It is very important that each step of the instructions is performed in the correct order. If these steps are not followed in sequence,assembly difficulties will occur.

About your furniture piece

●Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
●Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.
●Dust often and use a vacuum cleaner crevice tool to clean seams. To maintain the fabric appearance, gently clean soiled areas.
●Softening of foam is natural and will happen over time with use.
●Assemble on a soft surface to preventscratching the finish.
●Carefully remove all of the components from the packaging and set aside for assembly.

Power Lift Recliner Assembly Instructions

A



Backrest

B



Base

C



Lift Assist Remote Control

D



Massage & Heating Remote Control

E



Power Box

F



Power Cables

G



Power Cables

STEP 1

Attach Backrest to Base

·Align the backrest (A) with the slide rails on the base (B).
·Push down firmly until you hear an audible click.



Power Lift Recliner Assembly Instructions

STEP 2

Connect Power & Remotes

·Plug power cable (F) into the power box (E).

·Connect the lift assist remote (C), massage/heating remote (D) and power cable (G)to their ports on the chair's wiring harness.



You are all set!

FAQ

Type of common problem	Common problem	Possible cause	Solution
Installation	The backrest and the base of the clasp can not be aligned	The position of the base/backrest clasp is shifted during transportation	Tighten the clips until they align with the base/backrest clips
	The backrest is unstable after the product is installed	Snap at the base and backrest is stuck tight	Reinstall and check that the connection is stable
	Missing parts	Leakage	Please contact us to arrange new parts for you to reissue
Appearance	Backrest/armrest is not fluffy enough	Intemnal cotton was squeezed together during transportation	Open the cotton by tapping the problem area to make it fluffy
	The gap between the backrest and the base is large	Intemal cotton was crushed together during transport	Spread the cotton by tapping the bottom of the backrest to make it fluffy
	The gap between the base and armrest is large	Intemal cotton was squeezed together during transportation	By patting the armrests to spread the cotton to make it fluffy and reduce the gap
	Product surface leather has indentation	Indentation caused by squeezing during transportation	Gently blow the indentation with a hair dryer and smooth it out with your hands
Function	Foot rest can not be controlled to retract	The iron frame at the bottom of the foot rest is slightly bent	Break the iron frame can be retracted normally
	Heating temperature is low	in order to avoid damage to the leather fabric due to high temperature, we chose a low-temperature heating sheet	Wait for more than 10min, there will be low temperature effect
	Product lifting process stuck / does not work	Wires are not connected/not energized	Check whether the plug is well connected
		Damaged wire	If the wire is damaged, please contact us to send you a new wire
		Temporary short circuit inside the product	Remote control landing at the same time to the base pressure to make it fall to resume operation