
Couch Assembly Instructions



Need assembly help?
Scan the QR code for
a step-by-step video guide.

Important Safety Information:

Please read these instructions carefully before assembling the furniture.

Use appropriate tools for assembly.

1. Follow the assembly steps in the order provided. Do not skip any steps.
2. Small hardware may become loose inside the packaging during shipping. Please check all packaging materials carefully before discarding them to ensure that no parts are accidentally thrown away.
3. Regularly inspect all connections (screws, bolts, etc.) and ensure they remain securely tightened.
4. Keep this instruction manual for future reference.
5. If the instructions specify that assembly requires two or more people, do not attempt to assemble the product alone, as doing so may result in injury.

Note:

The product you purchased may slightly differ in appearance from the illustrations shown in this assembly manual.


Contact Us

Need help with your product? Our customer support team is here to assist you.

Email: support@smartragroup.com


We'll get back to you as soon as possible.

Hardware List

Item	Shape	Description	Qty
1		M5 x15 mm Hex Socket Self-Tapping Screw	42 + 2 Sparev
2		Allen Wrench	2
3		Hex Bit for Power Drill	1
4		White Connector Clip	2
5		45 cm Velcro Strap	12

1 Unpack and verify all components and hardware.

Reminder: Cushion filling may be packed separately. Please check all packages carefully before assembly.




Parts List

Item	Part Name	Qty.	Item	Part Name	Qty.
A	Right Arm Seat Frame	1	G	Left Armrest Cushion Cover & G filling	1
B	Left Arm Seat Frame	1	H	Right/Left Seat Back Pillow Cover & H filling	2
C	Armless Seat Frame	1	I	Right/Left Seat Cushion Cover & I filling	2
D	Front Leg	6	J	Middle Seat Back Pillow Cover & J filling	1
E	Rear Leg	6	K	Middle Seat Cushion Cover & K filling	1
F	Right Armrest Cushion Cover & F Filling	1			


2

Lift and unfold the backrest and armrests into their upright positions.



3


Remove the pre-installed screws from the seat frames.



4

Attach the front and rear legs using the screws removed in Step 3, as shown.

Reminder: Each rear leg is secured with **4 screws**, while each front leg is secured with **3 screws**. Install the rear legs at an angle to the back, as shown in the diagram.




5

Insert the cushion filling into the corresponding covers.

(Match each filling with the same lettered cover—for example, insert Filling F into Cover F).


Reminder: For the seat cushions, make sure the **shredded foam side faces up** as shown. You may need to unzip the seat cushion filling to check the shredded foam side.



6

Install the armrest cushions and velcro straps.


First, place the right and left armrest cushions (F and G) in position as shown. The armrest cushions already have velcro straps attached. Then attach the velcro straps (item 5) to the corresponding positions shown in the diagram.



7


Place the seat cushion as shown.

Reminder: Make sure the shredded foam side face up.




8

Place the back cushions as shown.



9


Secure the seat frames together using the white connecting clips, as shown.
Two clips are required to securely connect two seat sections and prevent them from shifting or separating.



Tip:
The clips may feel tight during installation. For easier assembly, connect them **one at a time.**
Hold the legs of the two adjoining sections and push them toward each other while installing the clip.
You may also place one side of the sofa against a wall for additional support or ask a friend to help.

10

Allow 3–7 days for the cushions to fully expand before they reach their final shape and support.
The cushions will gradually become fuller and more supportive during this time. Please allow sufficient time for complete expansion.



Care & Maintenance

Proper care helps keep your sofa comfortable and looking its best!

- **Keep It Indoors:** This sofa is for indoor use only.
- **Keep It Cool:** Keep away from heat, sunlight, and vents. No hot items on the surface.
- **No Jumping:** Children should not climb or jump on the sofa.
- **Everyday Cleaning:** Use a lint-free cloth or lint roller to remove dust and hair.
- **Spills & Stains:** Damp cloth with mild soap. Blot gently—don't rub. Air dry before use.