ASSEMBLY INSTRUCTIONS

Thank you for purchasing this quality product. Be sure to check all packed material carefully for small parts which may have come loose inside the carton during shipment. Place all parts on a clean smooth surface such as a rug or carpet to avoid scratching the parts. Be sure you have all the parts and hardware before you begin assembly.

NOTE : DURING ASSEMBLY , DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS HAVE BEEN INSTALLED.

| PART	DESCRIPTION	QTY
A	TABLE TOP	1
B	LEG	4
C	CROSS FRAME	1
D *	1/4"*12MM SCREW	8
E *	1/4"*16MM SCREW	8
F *	FLAT WASHER	8
G *	ALLEN KEY	1
*	PART OF HARDWARE KIT	

Thank you for purchasing our product!

Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days. We appreciate your business!

STEP -- 1

ATTACH LEGS(B) TO TOP(A) BY USING SCREW(D) , FLAT WASHER(F) AND ALLEN KEY(G) AS SHOWN.


STEP -- 2

ATTACH CROSS FRAME(C) TO ASSEMBLED UNIT BY USING SCREW(E) AND ALLEN KEY(G) AS SHOWN.

ASSEMBLY INSTRUCTIONS

Thank you for purchasing this quality product. Be sure to check all packed material carefully for small parts which may have come loose inside the carton during shipment. Place all parts on a clean smooth surface such as a rug or carpet to avoid scratching the parts. Be sure you have all the parts and hardware before you begin assembly.

NOTE : DURING ASSEMBLY , DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS HAVE BEEN INSTALLED.

Thank you for purchasing our product!

Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days. We appreciate your business!

PART	DESCRIPTION	QTY
A	SEAT BACK	2
B	LEFT LEG	2
C	RIGHT LEG	2
D *	SEAT CUSHION	2
E *	STRETCHER	2

PART	DESCRIPTION	QTY
F *	1/4"*12MM SCREW	12
G *	1/4"*35MM SCREW	8
H *	ALLEN KEY	1
*	PART OF HARDWARE KIT	

STEP -- 1

ATTACH CHAIR LEG(B&C) TO SEAT FRAME(D) BY USING SCREW(F) AND ALLEN KEY(H) AS SHOWN.

FRONT LEGS

FRONT OF SEAT

STEP -- 2

ATTACH STRETCHER(E) TO ASSEMBLED UNIT BY USING SCREW(F) AND ALLEN KEY(H) AS SHOWN .

STEP — 3

ATTACH SEAT BACK(A) TO ASSEMBLED UNIT BY USING SCREW(G) AND ALLEN KEY(H) AS SHOWN.

ASSEMBLY INSTRUCTIONS

Thank you for purchasing this quality product. Be sure to check all packed material carefully for small parts which may have come loose inside the carton during shipment. Place all parts on a clean smooth surface such as a rug or carpet to avoid scratching the parts. Be sure you have all the parts and hardware before you begin assembly.

NOTE : DURING ASSEMBLY , DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS HAVE BEEN INSTALLED.

Thank you for purchasing our product!

Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days. We appreciate your business!

PART	DESCRIPTION	QTY
A	SEAT BACK	2
B	LEFT LEG	2
C	RIGHT LEG	2
D *	SEAT FRAME	2
E *	SEAT CUSHION	2
F *	STRETCHER	2

| PART	DESCRIPTION	QTY
G *	1/4"*12MM SCREW	12
H *	1/4"*35MM SCREW	8
I *	WOOD SCREW	8
J *	ALLEN KEY	1
* PART OF HARDWARE KIT		

STEP -- 1

ATTACH SEAT FRAME(D) TO SEAT CUSHION(E)
BY USING WOOD SCREW(I) AS SHOWN.

STEP -- 2

ATTACH CHAIR LEG(B&C) TO THE ASSEMBLED
UNIT BY USING SCREW(G) AND ALLEN KEY(J).
AS SHOWN .

FRONT LEGS

FRONT OF SEAT

STEP — 3

ATTACH STRETCHER(F) TO CHAIR LEGS(B&C) BY
USING SCREW(G) AND ALLEN KEY(J) AS SHOWN.

STEP — 4

ATTACH SEAT BACK(A) TO ASSEMBLED UNIT BY
USING SCREW(H) AND ALLEN KEY(J) AS SHOWN.