



# UESR'S MANUAL


WJHM181WH

# Berore You Start



Read through each step carefully and follow the proper order

Separate and count all your parts and hardware



Give yourself enough room for the assembly process

Have the following tools:Flat Head Screwdriver,#2 philips Head Screwdriver and Hammer



Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.(Assembly speed can be increased by using electric screwdriver)

# Helpful Hints

## PEOPLE NEEDED FOR ASSEMBLY:1-2



- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify,sort and count the parts before attempting assembly.



- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an R(right) and L(left) for proper placement.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.



- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.




- Please fix all the screw provided for the back panel which can enhance product stability.If it is difficult to fix it when tightening ,it can be fixed with the help of a hammer and then tightened.



- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.


# Board Identification

Not actual size




1

FRAME
Qty: 2




2

SUPPORT BAR
Qty: 4




3

TOP BOARD
Qty: 1




4

SIDE BOARD
Qty: 2



5

SHELF BOARD
Qty: 1




6

SHELF BOARD
Qty: 1

# Part List



| Ⓐ | X4 |
|---|---|



| Ⓑ | X4 |
|---|---|



| Ⓒ | X1 |
|---|---|



M6*40mm

| Ⓓ | X8 |
|---|---|



M6*33mm

| Ⓔ | X12 |
|---|---|

spare:1



M6*12mm

| Ⓕ | X14 |
|---|---|

spare:1



M4*14mm

| Ⓖ | X12 |
|---|---|

spare:1



M4


| | X1 |
|---|---|




| | X1 |
|---|---|

# Board Identification


Not actual size




# Step 1


M6*40
D
X8
M6*33
E
X4
M4
X1
D
M6*40
1
2
2
1
2
2
Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.
A
A
A
A
E
M6*33
3


# Step 2


M6*12
F
X12
M4*14
G
X12
M4
X1
B
F
M4*14
G
G
F
M6*12
4
4
B
Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.


# Step 3



| M6*33 | M6*12 | M4 |
|---|---|---|
| Ⓔ X8 | Ⓕ X2 | X1 |




Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.



# Step 4

