Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.




- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.







Please look in the magic tape pouch for hardware packs and legs.

Sets often ship in multiple boxes and may arrive a day or two apart.





ACCENT CHAIR
N776P469982



Part List N776P469982


Label	Picture	Description	QTY
A		Back	1
B		Left Arm	1
C		Right Arm	1
D		Cushion	1
E		Bottom rail	1
F		Leg	4

Hardware N776P469982

Label	Picture	Description	QTY
①		Bolts 5/16"x50mm	7
②		Spring Washer 5/16"xØ13mm	7
③		Flat Washer 5/16"xØ19mm	7
④		Bolts 1/4"x20mm	5
⑤		Spring Washer 1/4"	5
⑥		Flat Washer 1/4"	5
⑦		Steel Bracket	2
⑧		Allen wrench	1
⑨		Plastic Washer	4

Assembly Preparation

Before Beginning Assembly:




①		X7
②		X7
③		X7
④		X5
⑤		X5
⑥		X5
⑦		X2
⑧		X1
⑨		X4

- Readinstructions, cover to cover-
- Have 2 adults on hand for assembly-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-

Assembly Steps


OVERVIEW





This Chair have multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Note: It is recommended that you have an adult partner to assist during the entire assembly process.


Step 1



① Bolts 5/16" x 6	② Spring Washer X6	③ Flat Washer x 6	⑧ Allen wrench
			


1.1 Attach the Cushion (D) to the Left Arm (B) and Left Right (C) by using Bolt (①) ,Spring Washers (②) and Flat Washers (③) with Open Wrench (⑧)as shown above.

Step 2



2.1 Attach the Back (A) to the Left Arm (B),Right Arm (C), Cushion (D) by using Hardware as shown above


Step 3



4 Bolts 1/4" x 4	5 Spring Washer X4	6 Flat Washer x 4	7 L -Shaped x2	8 Allen wrench

3.1 Attach the Bottom Rail (E) to the Left Arm (B) , Left Arm (C) by using Bolt (④) ,Spring Washers (⑤) and Flat Washers (⑥) , L-Shaped (⑦)with Open Wrench (⑧)as shown above.


Step 4



9 Plastic washer x 4

4.1 Install the Leg (F) to the Left Arm (B) ,Right Arm (C),Plastic Washer (9) as shown above

Step 5



Make sure all parts are connected and securely locked into position.
Your chair is ready for use.
This chair can only be used on a flat, level surface.