DINING TABLE

ASSEMBLY & HANDLING INSTRUCTIONS

IMPORTANT
SAFETY INFORMATION
This product weighs approximately
55 KG
HEAVY PRODUCT – HANDLE WITH CARE



MINIMUM 2 ADULTS
Required for lifting, moving and assembly. Never lift alone.



LIFT CORRECTLY
Bend your knees, keep back straight, lift using your legs.



DO NOT DRAG
Do not drag or slide the table on the floor. Lift with 2 people.



KEEP AWAY
Keep children and pets away from the assembly area.

WARNING: Take care when unpacking. Staples and wooden product protectors may have sharp edges or protruding points that could cause injury. Remove and dispose of all packaging carefully before assembly.

ASSEMBLY TIME	PEOPLE REQUIRED	PACKAGE CONTENTS
25–35 Minutes	2 Adults	2 Boxes

ASSEMBLY STEPS

1 Attach leg bolts (N) and spacers (J) to centre panel (D). Tighten using Allen Key (N).



2 Attach leg bolts (O) and spacers (M) to panel (E). Tighten using Allen Key (N).



3 Attach frame sections (H) and (G) together.



4 Attach the frame assembly to panel (B) using bolts (I), washers (K), spring washers (L) and spacers (N). Tighten using Allen Key (N).



5 Attach panel (B) to panel (C) using bolts (I), washers (K), spacers (N) and Allen Key (N).



6 Attach table top (A) to the assembled base using spacers (J) and bolts (N). Tighten using Allen Key (N).



7 Position the assembled table upright. Attach the pedestal wrap (F) by aligning it around the base and securing it in place. Ensure it is evenly positioned. 2 people recommended to pull tight to minimise gap.



PARTS LIST

A TABLE TOP — 1 PC	B UPPER PANEL — 1 PC	C LOWER PANEL — 1 PC	D CENTRE PANEL — 1 PC
E PANEL — 1 PC	F PEDESTAL WRAP — 1 PC	G FRAME SECTION — 1 PC	H FRAME SECTION — 1 PC

FIXINGS LIST

I BOLTS M8 x 20mm — 4 PCS	J SPACERS M8 x 20mm — 4 PCS	K WASHERS M8 — 4 PCS
L SPRING WASHERS M8 — 4 PCS	M SPACERS M8 x 20mm — 4 PCS	N ALLEN KEY — 1 PC
O LEG BOLTS M8 x 20mm — 4 PCS		

AFTER ASSEMBLY

Before use, check:

- ☐ All bolts are fully tightened.
- ☐ Table is level.
- ☐ Table does not rock.
- ☐ Protective feet are correctly fitted.
- ☐ No components have been damaged.



SAFE USE

- Indoor domestic use only.
- Maximum seating capacity: 4–6 persons.
- Do not stand or sit on the tabletop.
- Do not drag the table across the floor.
- Lift with two people whenever relocating the table.
- Inspect fixings regularly.
- Re-tighten all bolts after approximately 14 days of use and every 6 months thereafter.



CARE & MAINTENANCE



Wipe clean using a soft damp cloth.



Dry immediately after cleaning.



Do not use abrasive cleaners.

WARRANTY



This product comes with a 12 month warranty from the date of purchase.

This warranty covers manufacturing defects and faulty workmanship.

It does not cover damage caused by misuse, accidental damage, or normal wear and tear.

To make a claim under this warranty, please retain your proof of purchase and contact our Customer Service Team.