ASSEMBLY INSTRUCTION

Cart


Thank you for purchasing this quality product.Be sure to check all packing material carefully for small parts which may come loose inside the carton during shipment.Identify and count all parts and compare with the parts list below.Place all wooden furniture parts on a clean and flat soft surface,such as carpet or rug to prevent from being scratched.


PARTS LIST

NO	COMPONENT	QTY
1	Top Frame	1
2	Legs	4
3	Shelf with Holes	1
4	Shelf Panel	1
5	Wine Holder Front	1
6	Wine Holder Back	1
7	Towel Bar	1set

HARDWARE LIST

NO	DESCRIPTION	QTY
A	JCBC Screw Long	4
B	JCBC Screw Short	2
C	Spring Washer	6
D	Flat Washer	6
E	Allen Key	1
F	Wood Screw x32mm	4
G	Wood Screw x38mm	8
H	Castor with Lock	2
I	Castor without Lock	2






ASSEMBLY INSTRUCTION


Cart

Step 1




B JCBC Screw Short x2	
C Spring Washer x2	
D Flat Washer x2	
F Wood Screw 32mm x4	

Step 2




A JCBC Screw Long x3	
C Spring Washer x3	
D Flat Washer x3	

Step 3



A JCBC Screw Long x1	
C Spring Washer x1	
D Flat Washer x1	
F Wood Screw 38mm x8	

Step 4



H Castor with Lock x2	
I Castor without Lock x2	