Item Name : 10P Tent

****Helpful Tips:** Set up with 2 people for easiest assembly. Avoid over-tightening in windy conditions. Re-check stakes after first 10–15 minutes.

Ax1 	Bx1 	Cx1 	Dx1 	Ex13 
Fx25 	Gx1 			

Step 1: Assemble the Poles - Connect all pole sections together to form: Main center pole (C) & Support poles (B). Ensure each section snaps securely into place.



Step 2: Lay Out & Stake the Base - Spread the tent flat on a clean, level surface. Position the door where you want the entrance. Insert ground stakes through the base loops at a 45° angle for stability.



Fx12

Step 3: Raise the Tent - Insert the **main center pole (B)** through the top opening. Lift the tent upright by pushing the pole upward from inside. Adjust fabric evenly so all sides are balanced.



Step 4: Secure the Center Pole - Attach the **top cap (D)** to the center pole. Make sure the pole is centered and fully extended to support the tent shape.



Step 5: Stake & Tighten - Secure all remaining base loops using stakes **(F).** Attach and tighten the guy lines **(E)** around the tent. Pull lines outward evenly to create proper tension.



Ex13; Fx13

Step 6: Adjust Shape - Walk around the tent and tighten stakes/lines as needed. Ensure walls are taunt and the tent is evenly shaped.



Step 7: Final Setup - Secure the door panels and windows. Double-check all stakes and lines for stability. Your tent is now ready for use!

