

pull the fabric cord first to keep it more straight
⑤
④
②
③
⑥
①