











Owner Manual










Thank you for purchasing the Sectional Sofa.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At home we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great designs to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell. We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.






PARTS LIST (Carton A)

A x 2  Seat Cushion	B x 2  Seat Frame	C x 2  Seat Panel
D x 2  Back Frame	E x 2  Back Cushion	H x 8  Leg
1 x 8  Support Bar	2 x 12+1  Blot M6*20mm	3 x 2  Connection Plate
4 x 4  Metal Hook	5 x 4  Metal Clip	6 x 1  Allen Key 4mm
7 x 8+1  Plastic Washer	8 x 8+1  Felt pad	


PARTS LIST (Carton B)

F x 1  Left Arm	G x 1  Right Arm	H x 4  Leg
2 x 12+1  Blot M6*20mm	3 x 2  Connection Plate	4 x 4  Metal Hook
6 x 1  Allen Key 4mm	7 x 4+1  Plastic Washer	8 x 4+1  Felt pad


PARTS LIST (Carton C)

A x 2  Seat Cushion	B x 2  Seat Frame	C x 2  Seat Panel
H x 8  Leg	1 x 8  Support Bar	7 x 8+1  Plastic Washer
8 x 8+1  Felt pad		

STEP 1




STEP 2



NOTE: 48 hours to fully expand after being unpackaged !


STEP 3

2		x8
4		x4
6		x1




STEP 4

7		x8
8		x8




STEP 5

1		x8




STEP 6




STEP 7

2		x8
4		x4
6		x1




STEP 8

7		x4
8		x4




STEP 9




STEP 10

2		x4
3		x2




STEP 11




STEP 12

2		x4
3		x2




STEP 13


5		x6




STEP 14




STEP 15




STEP 16



STEP 17




STEP 18




Carton A * 2
Carton B * 1

STEP 19




STEP 20

7		x8
8		x8




STEP 21


1		x8




STEP 22



STEP 23




STEP 24




Carton A * 2
Carton B * 1
Carton C * 1

ASSEMBLY TYPE



Carton A * 1
Carton B * 1



Carton A * 2
Carton B * 1
Carton C * 2

MAINTENANCE AND WARNING 

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.
- The maximum load is 300 LBS/each.

WARRANTY

We strive to offer high ¡ quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!