

Dining Table

Assembly Instructions

CZ041 | 180CM



Assembly Overview




Parts List

1 Tabletop assembly

1200 × 800 × 130MM


Qty: 1



2 Leg

704 × Ø55MM


Qty: 4



3 Side panel (preinstalled)

300 × 800 × 20MM


Qty: 2



4 Slide rail (preinstalled)

930 × 72 × 30MM

Qty: 4




Hardware List

A Hex socket screw

M8 × 55MM


8 + 1 PCS



B Flat washer

M8 × 19MM


8 + 1 PCS



C Spring washer

M8


8 + 1 PCS



E Leveling foot (preinstalled)

M6 × Ø19 × 20MM

Qty: 4




Tool

D Hex key

M5 × 100MM


Qty: 1



Choose the Correct Screws


Using the correct screws helps prevent damage to components.

Example




Incorrect

Oversized screws can crack the panel.



Correct


Use the correct size screws.



Step 1

Attach legs (2) to tabletop assembly (1), as shown.


Hardware: A × 8, B × 8, C × 8 Tool: D × 1



Step 2

Rotate the preinstalled leveling feet (E) to level the table.
Assembly is complete. Extend the tabletop as needed.

Closed



Extended

