

FIREPLACE MANTEL

ASSEMBLY INSTRUCTION



If you have a problem with this product, DO NOT RETURN


PARTS LIST














PARTS AND ACCESSORIES

Tools required:


A screwdriver will be needed.




		
M8x30mm x24+1	x22+1	M6x12mm x 48 +1
		
M6x28mm x10+1	x10+1	x2+1
		
ST4X30mm x12+1	ST4X38mm x2	44X20mm x2
		
Ø 8x40mm x2	ST3.5X16mm x2	8*250mm x1

ASSEMBLY INSTRUCTIONS

01






ϕ8x30mm x2



ST4X30mm x2

02







x1



M6x12mm x2


03





ϕ8x30mm x4

04







x6



M6x12mm x12


05






ϕ8x30mm x4

06







x6



M6x12mm x12

07







M6x28mm x6



x6

08







M6x28mm x4



x4


09






ϕ8x30mm x4

10







x2



M6x12mm x4


11





ϕ8x30mm x4

12





x2




M6x12mm x4


13




ST4X30mm x10




14



ϕ8x30mm x6



15







x7




M6x12mm x14

16







ST3.5X16mm x2



44*20mm x1


17







Ø8x40mm x2

18






ST4X38mm x2




44*20mm x1

19



20



8*250mm x1

