

















Installation & Assembly










ASSEMBLY INSTRUCTION








ASSEMBLY INSTRUCTION


① 1PC 	② 1PC 	③ 1PC 	④ 1PC 
⑤ 2PCS 	⑥ 2PCS 	⑦ 4PCS 	⑧ 2PCS 
⑨ 2PCS 	⑩ 1PC 	⑪ 2PCS 	⑫ 2PCS 
⑬ 2PCS 	⑭ 2PCS 	⑮ 2PCS 	⑯ 1PC 

ASSEMBLY INSTRUCTION

A 6PCS	B 6PCS	C 10PCS	D 4PCS	E 32PCS
				
	Ø15X10	M6*35	M6*45	M5*38
F 12PCS	G 16PCS	H 2PCS	J 3PCS	K 4PCS
				
M6	M6*28	M6*65	Ø6*30	M6*40

L 2PCS	M 2PCS	N 2PCS	1PC	1PC	
					
M3.5*12	M6*30	M6*50			

STEP1




C 2PCS

M6*35

ASSEMBLY INSTRUCTION

STEP2

E 8PCS




STEP3

C 1PCS

M6*35


E 8PCS



ASSEMBLY INSTRUCTION

STEP4


C 2PCS	D 2PCS	F 2PCS
 M6*35	 M6*45	 M6



Be careful to align the holes correctly

STEP5

C 2PCS
 M6*35




Be careful to align the holes correctly

ASSEMBLY INSTRUCTION

STEP6

E 8PCS




STEP7

C 1PCS

M6*35


E 8PCS



ASSEMBLY INSTRUCTION


STEP8

C 2PCS	D 2PCS
M6*35	M6*45
F 2PCS	
M6	



STEP9


F 4PCS	M 2PCS
M6	M6*30
H 2PCS	
M6*65	



ASSEMBLY INSTRUCTION


STEP10

A	2PCS
J	1PC



STEP11


A	4PCS
J	2PCS



ASSEMBLY INSTRUCTION


STEP12

B 2PCS



STEP13


B 2PCS



ASSEMBLY INSTRUCTION

STEP14


B 2PCS



ASSEMBLY INSTRUCTION

STEP15

K 4PCS	F 4PCS
 M6*40	 M6
N 2PCS	
 M6*50	




ASSEMBLY INSTRUCTION

STEP16

G 16PCS

M6*28



ASSEMBLY INSTRUCTION

STEP17

L 2PCS	1PC	1PC
	