

BATHROOM CABINET N725P534062

Assembly Instructions - Please keep for future reference

Left or Right is up to you.





WARNING



This product is NOT a Clothing Storage Unit (CSU).

DO NOT use it for clothing storage.

Improper use may cause furniture tipover.




Two people are required to assemble and move this model.

Important – Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them
- Keep children and pets away from the installation area, which may cause choking if small parts are swallowed.
- Make sure you have enough space to layout the parts before
- Do not stand or apply weight to the product during assembly. This may cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damage to the unit or floor.
- It's easier for two people to assemble the parts together.



- To reduce the likelihood of damage to your product, make sure your power drill is set to a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- Check for loose screws on this unit from time to time.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are correctly tightened.

WARNING
In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-


Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type

Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the femle camlock as shown in the instruction.

Note：ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.



















The joint is now secure.



Assembly Instructions









Part List：N725P534062

①  1 PC	②  1 PC	③  1 PC	④  4 PCS
⑤  1 PC	⑥  1 PC	⑦  1 PC	⑧  1 PC
⑨  1 PC	⑩  1 PC	⑪  1 PC	⑫  1 PC
⑬  2 PCS	⑭  3 PCS	⑮  3 PCS	⑯  3 PCS
⑰  3 PCS	⑱  4 PCS	⑲  1 PC	 Hardware 1 PC

Hardware list： N725P534062


Please check you have all the panels listed below


Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Male Camlock x 64+2 (pcs)	B  Female Camlock x 64+2 (pcs)	C  Dowel (6x30) x 38+ 5(pcs)
D  x 2 (sets)	E  M5*45mm Screw x 20+1(pcs)	F  Door Hinge X 4(pcs)
G  798mm x 2(pcs)	H  3.5*14mm Screw x 24+2(pcs)	I  Plasticwedge x 16+1(pcs)
J  3*16mm Screw x 16+1(pcs)	K  Handle & Fixings x 1 (set)	L  Wall Fixing Pack x 2(sets)
M  Shelf Support Pin x16+1 (pcs)	N  Ø21 Sticker x 28+2(pcs)	O  Hex Key M3 x 1(pc)
P  Phillips screwdriver x 1(Pc)		


Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws






The screws length is measured from the head to the point (30mm screw shown).


Assembly Instructions


Step 1

L/R












Step 2

L/R










Step 3

L/R










Step 4

L/R










Assembly Instructions

Step 5


L







Top





Bottom


If you choose left orientation, please follow this "L" step.

Step 5


R







Top




Bottom

If you choose right orientation, please follow this "R" step.

Assembly Instructions

Step 6


L



If you choose left orientation, please follow this "L" step.

Step 6

R




If you choose right orientation, please follow this "R" step.

Assembly Instructions

Step 7

L

Bottom




If you choose left orientation, please follow this "L" step.

Step 7

R

Bottom



If you choose right orientation, please follow this "R" step.


Assembly Instructions

Step 8

L

Bottom

E x 8




If you choose left orientation, please follow this "L" step.

Step 8

R

Bottom

E x 8




If you choose right orientation, please follow this "R" step.


Assembly Instructions

Step 9

L



Top




If you choose left orientation, please follow this "L" step.


Bottom

Step 9

R



Top



If you choose right orientation, please follow this "R" step.


Bottom

Assembly Instructions

Step 10

L

E x 8




If you choose left orientation, please follow this "L" step.

Step 10

R


E x 8





If you choose right orientation, please follow this "R" step.

Step 11

L










If you choose left orientation, please follow this "L" step.

Step 11

R









If you choose right orientation, please follow this "R" step.


Assembly Instructions


Step 12

L/R













Step 13

L/R












Step 14

L









Two people are required to assemble and move this model.

If you choose left orientation, please follow this "L" step.

Step 14

R






Two people are required to assemble and move this model.


If you choose right orientation, please follow this "R" step.


Assembly Instructions


Step 15


L














If you choose left orientation, please follow this "L" step.


Step 15


R













If you choose right orientation, please follow this "R" step.


Assembly Instructions


Step 16

L












If you choose left orientation, please follow this "L" step.


Step 16

R











If you choose right orientation, please follow this "R" step.


Step 17


X3


L/R





























Step 18

L/R










Step 19

L/R










Step 20

L/R









Assembly Instructions


Step 21


L




If you choose left orientation, please follow this "L" step.











Two people are required to assemble and move this model.


Step 21


R




If you choose right orientation, please follow this "R" step.











Two people are required to assemble and move this model.


Assembly Instructions

Step 22

L










If you choose left orientation, please follow this "L" step.

Step 22

R








If you choose right orientation, please follow this "R" step.


Step 23


L





DANGER - To prevent furniturefrom toppling attach, mount, boltor otherwise secure to walls andfloors.
Do not put heavy items ontop shelves.
Do not place unstablefurniture near where children play.
An anchor kit suitable for plasterwalls is included with this item, if you require a different kit consultyour nearest hardware store.






If you choose left orientation, please follow this "L" step.


Step 23


R





DANGER - To prevent furniturefrom toppling attach,
mount, boltor otherwise secure to walls andfloors.
Do not put heavy items ontop shelves.
Do not place unstablefurniture near where children play.
An anchor kit suitable for plasterwalls is included with this item,
if you require a different kit consultyour nearest hardware store.





**If you choose right orientation,
please follow this "R" step.**

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied wich your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.For light loads,general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving,wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads




For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance


Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

LEFT



RIGHT



FINISH

Made in Vietnam