
INSTRUCTION MANUAL

70inch TV Cabinet
with 36inch fireplace

HKTS010-BK



WELCOME TO THE FUTURE OF HOME ENTERTAINMENT!

Thank you for choosing our new electric fireplace and TV stands! Our products are designed to be both stylish and functional, with a focus on energy efficiency and sustainability.

We use high-quality materials to ensure that our pieces are built last, so you can enjoy them for years. Whether you're looking for a cozy electric fireplace or a stylish TV stand, we have something for everyone.

Our products are perfect for any home or office, and we're confident that you'll love them as much as we do!

Hey guys, congratulations on getting a nice fireplace TV stand. Thanks for supporting us. Your package will be divided into two, we are sent out at the same time, but due to the uncontrollable logistics. If you receive one package first please be patient, your second package is not far from receiving. Thank you for your understanding and waiting, contact us Wolfthontech1@gmail.com at the first time if you have any questions!

NOTICE

1.Children are not allowed to operate
2. Faster installation is possible with power tools.
3. Do not pull the door vigorously to prevent the storage cabinet from tipping over.
4.Please attach the storage cabinet to the wall with an anti-tip device after installation is complete.
5. When using the storage cabinet for the first time,please keep it in a ventilated environment to allow the smell to fully evaporate.
6.When placing the partitions,please make sure the nails are firmlyinstalled to prevent the partitions from falling off.
7. If any parts are missing,broken,damaged or worn,discontinue use of the product until repairs are made and/or factory replacement parts are installed
8. Do not use this product in a manner inconsistent with the manufacturer's instructionsas this may void the product warranty
9.If accessories are missing, please contact customer service for communication in time, we provide 7x24 hours after-sales service
10.Do not use any attachments or accessories other than the original factory attachments and accessories
11.Do not alter this equipment. Any alteration will create a safety hazard.
12.Please do not seat on the board, warping preventing.
13.When moving cabinets, please apply force on the cabinet below. Try not to carry the top board alone as it is easy to deform.

BEFORE YOU START

⚠ Please read all instructions carefully.
⚠ Retain instructions for future reference.
⚠ Separate and count all parts and hardware.
⚠ Read through each step carefully and follow the proper order.
⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product un-necessarily once assembled.
⚠ Always place the product on a flat, steady and stable surface.
⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

PRE-INSTALLATION

GRAB YOUR TOOLS


Phillips Screwdriver

2 Persons Assembly

Up to 40 Minutes For Assembly


WHAT'S IN THE BOX

1




1PCS

2




1PCS

3




1PCS

4




1PCS

5




1PCS

6




2PCS

7




2PCS

8



1PCS

9




1PCS

10




2PCS

11




1PCS

12



2PCS


13



2PCS

HARDWARE

A




8*30mm 8PCS

B




15*12mm 28+2PCS

C



6*43mm 28+2PCS

D




1PCS

E



K3.5*14mm 6+1PCS

F




2PCS

G



4PCS

H




M6*20mm 4+1PCS

I




8+1PCS

J



1PCS

K




6PCS

L




K3*14mm 12+1PCS

M




2PCS

N




M6*20mm 4+1PCS

O



1PCS

PREVIEW IMAGE OF THE INSTALLATION BOARD




PRODUCT ASSEMBLY

STEP 1

Attach 2 pcs C to ⑪ corresponding hole.


NOTE:
If the white plastic can't be pressed in, use a tool to gently knock it down.

	C x 2PCS



STEP 2

Connect the ⑪ and 2 pcs ⑫ with 2 pcs B respectively, and turn the screws clockwise.




	B x 2PCS

PRODUCT ASSEMBLY

STEP 3


Attach the 8 pcs C to the corresponding holes in ③, note that it is the non-slotted side. Attach J1 to ③ with K and L.

	C x 6PCS
	J1 x 1PCS
	K x 6PCS
	L x 12PCS



STEP 4

Connecting STEP2 and STEP3 grouped sections.




	B x 6PCS

PRODUCT ASSEMBLY


STEP 5

Flip-fit STEP3 and install the 4 pcs C on the corresponding holes.



STEP 6

Connect ⑥ and ⑩ with 2 pcs A, and in the same way install another ⑥ and ⑪.




A x 4PCS

X2


PRODUCT ASSEMBLY

STEP 7

	A x 2PCS
	B x 4PCS



STEP 8




	C x 8PCS

PRODUCT ASSEMBLY


STEP 9

Connect ③ and ④⑤ with 4 pcs B; Connect ⑪ and ④⑤ with 4 pcs B.




STEP 10

Push ③ into the bottom along the slot of ④/⑤/⑥, and note that it needs to be stuck into the slot of ③.




PRODUCT ASSEMBLY

STEP 11



STEP 12




PRODUCT ASSEMBLY

STEP 13

After M1 is installed, snap M2 into 1 pcs I.


M1 has a beveled opening towards the back of the cabinet (the panel is slotted i.e. the back of the cabinet)



	C x 8PCS
	E x 4PCS
	M1 x 2PCS
	M2 x 2PCS

STEP 14

Connect the two parts of STEP12 and STEP13 with 4 pcs H.




	H x 4PCS

PRODUCT ASSEMBLY


STEP 15

	A x 2PCS
	B x 8PCS



STEP 16

Install D and run D's wires through hole ⑬.




	E x 2PCS
	D x 1PCS

PRODUCT ASSEMBLY

STEP 17

I corresponds to a number of rows of holes ⑦ can be adjusted up and down according to demand




I x 8PCS

PRODUCT ASSEMBLY

STEP 18


First install a pair of F on ⑧, and in the same way install the other door plate ⑨.

	M3 x 2PCS
	M4 x 2PCS
	F x 2PCS



STEP 19


After installing the F, remove the lamination from the front of the door panel. If there are any residual marks, simply wipe them off with a damp towel after the cabinet is installed.




PRODUCT ASSEMBLY


STEP 20


When installing ⑨ to ⑤, first install the four screws of the oval hole of F (corresponding to the four small holes of ⑤), close ⑨ and see whether the position of ⑨ is suitable, if not, you can adjust the position of up and down, left and right through the screws of F. Adjust the position of the four round holes of F and then lock the screws of the four round holes of F after adjusting the position. In the same way, will ⑧ installed on ④.







Door Adjustment Schematic










PRODUCT ASSEMBLY

STEP 21

Connect the reserved wires for the light strip on ① with J1 and J2.


	J2 x 1PCS



ELECTRONIC FIREPLACE INSTALLATION

STEP 22


Remove four silver screws from the sides of the heaterm, two screws on each side.
Remove two screws from the front of the heater.
Remove the tempered glass by lifting it from the lugs on the side.



STEP 23

Take the glass from the appliance first,the gently put the appliance to the TV Stand by two persons.


Fix the appliance to the TV stand with 4 black screws according to the hole position



ELECTRONIC FIREPLACE INSTALLATION

STEP 24


Place the front glass surround over the front of the fire aligning the slot in the bracket at each side of the glass pandel with the lugs on the sides of the fire .




ELECTRONIC FIREPLACE INSTALLATION

STEP 25

Fix the tempered glass with 2pcs of 4*8mm screws provided.





All Finished-Congratulations! You made it!
Why not show off your hard work?

HELP CENTER

Question about your product? We're here to help. Visit us at:



Chat Support


Product inquiry



Orders FAQ


Product Assembly



Returns & Refunds

WE STAND BEHIND THE QUALITY OF OUR FURNITURE

1. If you have any issues with your item, please let us know! We will always do our best to come up with a solution that you will be happy with.
2. Please get in touch with our customer service team before returning the product.
3. And please do not throw away the original box(es) if you have not finished assembling and confirmed no quality issues.

Length of return period:
You can return items within 30 days of purchase
In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:
1. Your item has a manufacturing defect in materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after you send us photos or videos of the defect.
2. Your item has been damaged in transit. For example, glass is broken or product is damaged. We will send you a prepaid shipping label after you send us photos of the damage.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after you send us photos of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

* However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

1.You don't like the product(s) after receiving the box(es).
2.You no longer need the product(s) but have received the box(es).
3.You buy the product(s) by mistake but have received the box(es).
4.Order/shipment cancellation failed, and you have received the box(es).

Return Request

In order to get a full refund as described in this return policy, all items must be:

1.In a brand new/unused condition. Please provide photos before and after packaging.
2.When returning, all accessories and parts must be firmly packed in all original packaging. If your return does not meet these requirements, you may not receive a full refund.

When will I be refunded?

The refund is issued once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us via email, and we will work on a solution to ensure your satisfaction.

HELP CENTER

Confuzzled? Email Our Customer Serivice At:

YouTube :BREEZEHEAT

CONTACT INFO: Wolfthontech1@gmail.com

Please feel free to **send us the text or email.** We will reply to you within 24 hours. Also please feel free to contact us if you have received the defective items.

Follow our YouTube Channel then you will be able to find our **assembling video** as a pinned video.

SAVE THESE INSTRUCTIONS