
# ASSEMBLY INSTRUCTIONS
## DINING TABLE





**NOTE TO CUSTOMERS:**




- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

# ASSEMBLY INSTRUCTIONS

## PARTS IDENTIFICATION

| | | | |
|---|---|---|---|
| 1- | Table Top |  | 1 pc |
| 2- | Table Legs |  | 4 pcs |

## HARDWARE IDENTIFICATION

| | | | |
|---|---|---|---|
| A- | Allen Key M4 |  | 1 pc |
| B- | JCBC Bolt M6 x 70mm |   | 8 pcs |
| C- | Spring Washer 1/4” |   | 8 pcs |
| D- | Flat Washer 1/4“ |   | 8 pcs |

NOTE: Quantities shown are for one table.
Bolts are metric screw threads

