210x285mm 安装使用说明书 英文版

DRIJA

Installation Instructions



Faucet Fittings



NO.	Item name	Amount
15	Double nut connection hose	1
14	Soap dispenser bottle	1
13	Connection tube of pull-out hose	1
12	AA battery	4
11	Tee Connector	1
10	Mobile phone holder	1
9	Handheld spray gun connection tube	1
8	Multifunctional spray head	1
7	Handheld spray gun	1
6	Purified faucet tube	1
5	Red and blue water inlet pipes	2
4	Heptagonal faucet shell	1
3	Gravity ball	2
2	Pull-out hose	2
1	Waterfall kitchen faucet	1

Step One



Remove the two screws with a Phillips screwdriver, take out the battery compartment, put the #5 batteries in, then put them back in and re-screw the screws in place.

Step Two



Remove the four nuts

Step Three



Remove the four nuts

Step Four



Install the nut removed in the previous step in turn, and after the soap dispenser bottle is filled with detergent, install it on it as well.

Step Five



Install the 2 pull-out hoses, the handheld spray gun, the pull-out heptagonal hose, the multi-function spray head, and the water purification elbow, in order, as shown in the diagram.

Step Six



Step Eight



Install the sink drainer.

Step Nine



DRIJA

Step Ten



Step Eleven



Installing the phone holder with a Phillips screwdriver.

Usage



Precautions after installation

☆After the installation is completed, please check the sealing condition of each connection, and there should be no leakage in each place.

☆Using conditions: the working water pressure of the faucet is 0.05-1.0MPa (including cold water and hot water pressure), applicable water temperature: 4-90°C

☆Faucet and hot and cold water supply pipe must be connected correctly, that is, facing the front of the faucet, the left side to connect the hot water, the right side to connect the cold water;

☆After installation, the braided hose must not kink.

Cleaning care

In order to maintain the faucet's shiny appearance and good performance, please take care of the faucet as follows:

1. Rinse with water only and dry with a soft cotton cloth;
2. Mild liquids and colorless glass cleaners can be used to remove surface dirt and film, as well as non-abrasive brightening agents;
3. Never use abrasive cleaners, polishes, emery cloths, paper towels or squeegees;
4. Do not use acidic cleaners, insoluble granular cleaners, soaps, etc.
5. During usage, the bubblers may accumulate dirt and slow down the flow of water. Simply unscrew the bubbler, rinse the bubbler with water and install it back in place.